



Mercedes-Benz

MERCEDES-BENZ® 1987–2013

VERSION: V2013.11 DATE: DEC., 2013

AVAILABLE MODELS LIST

MODELS	CHASSIS TYPE
A-class	168, 169, 176
B-class	245, 246
C-class	201, 202, 203, 203-CAN, 204
E-class	124, 210, 211, 212, 207(coupe)
S-class	126, 140, 220, 220-CAN, 221
SLK-class	170, 171, 172
CLK-class	208, 209, 209-CAN
SL-class	107, 129, 230, 230-CAN, 231
SLR	199
SLS	197
CLS-class	219, 218
CL-class	215, 215-CAN, 216
R-class	251
M-class	163, 164, 166
G-class	463
GL-class	X164, X166
GLK-class	X204
V-class and Transporter (MB-3)	SPRINTER, VITO, Vaneo, VITO 638 / 639, VIANO 639, SPRINTER 906, VITO / VIANO China 636

* If the models are not listed here, users could select the related models.

A-class, 168 with *QUICK SERVICE

DRIVE	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ECM/MSM (Engine Control Monolith)	✓	✓	✓	✓	
CDI 1 (Common Rail Diesel Injection)	✓	✓			
ACS (Automatic Clutch System)	✓	✓		✓	
FTC (Front Transmission Control)	✓	✓			
GRM (Gear Recognition Module)	✓	✓	✓		

CHASSIS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ESP (Electronic Stability Program)	✓	✓			

BODY	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
AB (SRS / Airbag)	✓	✓			
ATA (Anti-Theft Alarm)	✓	✓			
LCP (Lower Control)	✓	✓	✓		
RFL (Radio Frequency Locking)		✓			

INFO. and COMMUNICATION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ICM (Instrument Cluster)	✓	✓		Service Reset / Oil Quality	
PTS (Parktronic System)	✓	✓			
D2B (AUDIO System)	✓	✓		✓	
CDC (CD Changer)		✓			
CTEL1 (Cellular Telephone 1)		✓			
CTEL2 (Cellular Telephone 2)		✓			
APS (Auto Pilot)		✓			

SEATS AND DOORS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
DCM 1	✓	✓	✓		
DCM 2	✓	✓	✓		
DCM 3	✓	✓	✓		
DCM 4	✓	✓	✓		

AIR CONDITION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
TAC / TAU (Tempmatic Air conditioning)	✓	✓			
STH (Stationary Heater)		✓			

***QUICK SERVICE:** Perform "Service Reset" within seconds.

A-class, 169 with *QUICK SERVICE

DRIVE	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
FCVT (Continuously variable automatic transmission)	✓	✓			
SIM266 (Engine system)	✓	✓			
ESM (Electronic Selector Module)	✓	✓		✓	
CDI A(Common Rail Diesel Injection)		✓			
CDI 4(Common Rail Diesel Injection)	✓	✓		✓	

CHASSIS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ESP (Electronic Stability Program)	✓	✓			
ES (Electrical power steering)	✓	✓			

BODY	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
AB (SRS / Airbag)	✓	✓			
CGW (Central gateway)		✓			
EIS (Electronic ignition switch, without Keyless Go)	✓	✓			
OCP (Overhead control panel)	✓	✓			
SAM (Signal acquisition and actuation module)	✓	✓			
HRA-FL		✓			
HRA-FR		✓			

INFO. and COMMUNICATION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ICM (Instrument Cluster)	✓	✓		Service Reset	
PTS (Parktronic System)	✓	✓			
SCM(Steering column module)	✓	✓			
ASSYST-PLUS	✓	✓		Service Reset	

SEATS AND DOORS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
DCM FL	✓	✓	✓		
DCM FR	✓	✓	✓		
DCM RL		✓			
DCM RR		✓			

AIR CONDITION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
C-AAC(Convenience automatic air conditioning)	✓	✓	✓	✓	

A-class, 176 with *QUICK SERVICE

DRIVE	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
MED40	✓	✓			
DCT	✓	✓			
FSCU(Fuel pump)	✓	✓			
SCR	✓	✓			
CDID 3	✓	✓			

CHASSIS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ESP (Electronic Stability Program)	✓	✓			
EPB (Electronic parking brake)	✓	✓			
AIRmatic (Suspension)	✓	✓			
EPS(Electrical power steering)	✓	✓		✓	
TPC(Tire Pressure Control)	✓	✓			

BODY	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
EIS (Electronic Ignition Switch)	✓	✓			
AB (SRS / Airbag)	✓	✓			
SAM	✓	✓			
RevETR-LF	✓	✓			
RevETR-RF	✓	✓			
ATA		✓			
SGSW(Headlamp)		✓			
PSD (Control module 'Panoramic sliding roof)	✓	✓			

INFO. and COMMUNICATION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ICM(Instrument Cluster)	✓	✓	✓	✓ (Service reset)	
SCM (Steering Column Module)	✓	✓	✓		
PTS (Parktronic System)	✓	✓			
MFK(Multifunction camera)	✓	✓			
RFK (Backup camera)	✓	✓			

SEATS AND DOORS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
DCM FL	✓	✓	✓		
DCM FR	✓	✓	✓		
DCM RL	✓	✓	✓		
DCM RR	✓	✓	✓		

ESA – Driver	✓	✓			
ESA – Passenger	✓	✓			
AIR CONDITION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
AAC (Automatic Air Conditioning)	✓	✓		✓	

B-class, 245 with *QUICK SERVICE

DRIVE	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
FCVT (Continuously variable automatic transmission)	✓	✓			
SIM266 (Engine system)	✓	✓			
ESM (Electronic Selector Module)	✓	✓		✓	
CDI A(Common Rail Diesel Injection)		✓			
CDI 4(Common Rail Diesel Injection)	✓	✓		✓	

CHASSIS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ESP (Electronic Stability Program)	✓	✓			
ES (Electrical power steering)	✓	✓			

BODY	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
AB (SRS / Airbag)	✓	✓			
CGW (Central gateway)	✓	✓			
EIS (Electronic ignition switch, without Keyless Go)	✓	✓			
OCP (Overhead control panel)	✓	✓			
SAM (Signal acquisition and actuation module)	✓	✓			
XALWA-L (Xenon headlamp, left)	✓	✓			
XALWA-R (Xenon headlamp, right)	✓	✓			
AHE (Trailer recognition)	✓	✓			

INFO. and COMMUNICATION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ICM (Instrument Cluster)	✓	✓		Service Reset	
ASSYST PLUS (PLUS Active Service System)	✓	✓		Service Reset	
PTS (Parktronic System)	✓	✓			
SCM(Steering column module)	✓	✓			

SEATS AND DOORS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
DCM 1	✓	✓	✓		
DCM 2	✓	✓	✓		
DCM 3	✓	✓	✓		
DCM 4	✓	✓	✓		

AIR CONDITION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
C-AAC(Convenience automatic air conditioning)	✓	✓	✓	✓	

B-class, 246 with *QUICK SERVICE

DRIVE	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
MED40	✓	✓			
CDID 3	✓	✓			
DCT	✓	✓			
FSCU(Fuel pump)	✓	✓			
DTR (Distronic)	✓	✓			

CHASSIS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ESP (Electronic Stability Program)	✓	✓			
EPB (Electronic parking brake)	✓	✓			
EPS(Electrical power steering)	✓	✓			
TPC(Tire Pressure Control)	✓	✓			

BODY	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
AB (SRS / Airbag)	✓	✓			
EIS (Electronic Ignition Switch)	✓	✓			
SAM	✓	✓			
RevETR-LF	✓	✓			
RevETR-RF	✓	✓			
SVMCM	✓	✓			
PSD(Panoramic sliding roof)	✓	✓			
ATA		✓			

INFO. and COMMUNICATION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ICM(Instrument Cluster)	✓	✓	✓	✓ (Service reset)	
PTS (Parktronic System)	✓	✓			
SCM (Steering Column Module)	✓	✓	✓		
PTS (Parktronic System)	✓	✓			
MFK(Multifunction camera)	✓	✓			
RFK (Backup camera)	✓	✓			

SEATS AND DOORS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
DCM FL	✓	✓	✓		
DCM FR	✓	✓	✓		
DCM RL	✓	✓	✓		
DCM RR	✓	✓	✓		
ESA – Driver	✓	✓			

ESA – Passenger	✓	✓			
HKS (Tailgate control)	✓	✓			

AIR CONDITION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
AAC (Automatic Air Conditioning)	✓	✓		✓	
STH (Stationary heater with remote control)		✓			

C-class, 201

SYSTEM	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
CIS-E		✓			
ELR (Diesel Injection Electronic ISC)		✓			
ESCM		✓			
ASD (Automatic Locking Differential)		✓			
AB (SRS / Airbag)		✓			
Climate Control		✓			

C-class, 202

DRIVE	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
LH-SFI	✓	✓	✓	✓	
HFM-SFI	✓	✓	✓	✓	✓
PMS/PEC	✓	✓			
ME 2.0 / 2.1	✓	✓	✓	✓	✓
SIM4LE	✓	✓		✓	
EA / CC / ISC (with LH-SFI / HFM-SFI)	✓	✓			
DM	✓	✓		✓	
EAG 722.5 (5-speed automatic ETC)	✓	✓	✓		
EGS 722.6 (5-speed automatic ETC)	✓	✓	✓	✓	
IFI / ERE (Electronic Inline injection)	✓	✓			

CHASSIS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ABS	✓	✓			
ASR	✓	✓			
ETS	✓	✓			
ESP (Electronic Stability Program)	✓	✓			
BAS (Brake Assist System)	✓	✓			
ADS (Adaptive Damping System)		✓			

C-class, 202 (continued)

BODY	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
AB (SRS / Airbag)	✓	✓			
EIS (Electronic Ignition Switch)	✓	✓		✓	
ATA (Anti-Theft Alarm)	✓ (before 97)	✓			
PSE	✓ (before 97)	✓			
SAM	✓	✓	✓	✓	
OCP	✓	✓	✓		
LCP (Lower Control)	✓	✓	✓		
HRA		✓			
SVMCM		✓			

INFO. and COMMUNICATION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ICM / KI (Instrument Cluster)	✓	✓		Service Reset / Oil Quality	
PTS (Parktronic System)	✓	✓			
D2B (AUDIO System)	✓	✓		✓	
CDC (CD Changer)		✓			
CTEL1 (Cellular Telephone 1)		✓			
CTEL2 (Cellular Telephone 2)		✓			
VCS		✓			
TELE AID(K-wire)		✓			
DN(K-wire)		✓			
APS (Auto Pilot)		✓			

SEATS AND DOORS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
DCM 1	✓	✓	✓		
DCM 2	✓	✓	✓		
DCM 3	✓	✓	✓		
DCM 4	✓	✓	✓		
ESA-FL	✓	✓			
ESA-FR	✓	✓			

AIR CONDITION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
TAC / TAU (Tempmatic Air conditioning)	✓	✓		✓	
STH (Stationary Heater)	✓	✓			

C-class, 203-CAN with *SHORT TEST

DRIVE	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ME 2.0 / 2.1	✓	✓	✓	✓	✓
ME 2.8 / 2.8 AMG	✓	✓	✓	✓	
ME 9.7	✓	✓	✓	✓	
SIM4LE	✓	✓		✓	
SIM271	✓	✓			
EGS 722.6 (5-speed automatic ETC)	✓	✓	✓	✓	
EGS 722.6 (5-speed automatic SEQ)	✓	✓			
EGS 722.9	✓	✓		✓	
ESM (Electronic Selector Module)	✓	✓		✓	
DTR (Distronic)		✓			
CDI 3	✓	✓			
CDI 4	✓	✓		✓	

CHASSIS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ESP (Electronic Stability Program)	✓	✓	✓	✓	

BODY	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
CGW (Central Gateway)		✓			
EIS (Electronic Ignition Switch) / KG (keyless)	✓	✓		✓	
AB (SRS / Airbag)	✓	✓			
SAM-FRONT	✓	✓	✓		
SAM-REAR	✓	✓			
OCP	✓	✓		✓	
LCP (Lower Control)	✓	✓			
UCP (Upper Control)	✓	✓			
HRA-FL	✓	✓			
HRA-FR		✓			
WSS (Weight Sensing System)	✓	✓		✓	
AHE (Trailer recognition)		✓			
SVMCM		✓			

*SHORT TEST: Searching for all systems, clear fault code if existed in one button.

C-class, 203-CAN with *SHORT TEST (continued)

INFO. and COMMUNICATION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ICM(Instrument Cluster)	✓	✓		✓ (more workshop functions)	
SCM (Steering Column Module)	✓	✓			
PTS (Parktronic System)	✓	✓			
MOST – AGW	✓	✓		✓	
MOST – COMMAND / AUDIO		✓			
MOST – CDC (CD Changer)		✓			
MOST – HFS (Handsfree System and Microphone)		✓			
MOST – CTEL (Cellular Telephone)		✓			
MOST – VCS (Voice Control)		✓			
MOST – NAVI (Navigation)		✓			
MOST – SOUND (Bose SOUND System)		✓			
MOST – TV (TV Tuner)		✓			
MOST – SDAR (Satellite Radio)		✓			

SEATS AND DOORS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
DCM FL	✓	✓	✓		
DCM FR	✓	✓	✓		
DCM RL	✓	✓	✓		
DCM RR	✓	✓	✓		
ESA – Driver	✓	✓			
ESA – Passenger	✓	✓			

AIR CONDITION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
AAC (Automatic Air Conditioning)	✓	✓	✓	✓	
STH (Stationary Heater)	✓	✓			

C-class, 203 (non-CAN) with *QUICK SERVICE and *SHORT TEST

DRIVE	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ME 2.0 / 2.1	✓	✓	✓	✓	✓
ME 2.8 / 2.8 AMG	✓	✓	✓	✓	
SIM4LE	✓	✓		✓	
SIM4LSE	✓	✓		✓	
EGS 722.6 (5-speed automatic ETC)	✓	✓	✓	✓	
EGS 722.6 (5-speed automatic SEQ)	✓	✓			
ESM (Electronic Selector Module)	✓	✓		✓	
DTR (Distronic)		✓			
CDI 2 (Common Rail Diesel Injection)	✓	✓	✓		

CHASSIS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ESP (Electronic Stability Program)	✓	✓		✓	
BAS (Brake Assist System)	✓	✓			
VP (Vacuum Pump Brake Booster)	✓	✓			

BODY	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
EIS (Electronic Ignition Switch)	✓	✓		✓	
AB (SRS / Airbag)	✓	✓			
KG (keyless Go)	✓	✓			
PSE	✓ (before 97)	✓			
SAM-FRONT	✓	✓	✓	✓	
SAM-REAR	✓	✓		✓	
OCP	✓	✓		✓	
LCP	✓	✓			
UCP	✓	✓			
HRA-FL	✓	✓			
HRA-FR		✓			
AHE (Trailer recognition)		✓			
SVMCM		✓			

*SHORT TEST: Searching for all systems, clear fault code if existed in one button.

*QUICK SERVICE: Perform "Service Reset" within seconds.

C-class, 203 (non-CAN) with QUICK SERVICE & SHORT TEST (continued)

INFO. and COMMUNICATION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ICM (Instrument Cluster)	✓	✓	✓	✓ (more workshop functions)	✓
SCM (Steering Column Module)	✓	✓			
PTS (Parktronic System)	✓	✓			
D2B (AUDIO System)	✓	✓		✓ (include TV on Drive)	
CDC (CD Changer)		✓			
CTEL1 (Cellular Telephone 1)		✓			
CTEL2 (Cellular Telephone 2)		✓			
VCS		✓			
TELE AID / E-Call		✓			
TV		✓			
SOUND		✓			

SEATS AND DOORS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
DCM FL	✓	✓	✓		
DCM FR	✓	✓	✓		
DCM RL	✓	✓	✓		
DCM RR	✓	✓	✓		
ESA – Driver	✓	✓			
ESA – Passneger	✓	✓			

AIR CONDITION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
C-AAC / AAC / HEAT	✓	✓	✓	✓	
REAR AC		✓			
STH (Stationary Heater)	✓	✓			

C-class, 204 with *SHORT TEST

DRIVE	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ME 9.7	✓	✓	✓	✓	
ME 9.7AMG	✓	✓			
MED9.7	✓	✓			
MED40	✓	✓			
SIM271	✓	✓			
ME2.7.2	✓	✓			
EGS 722.6 (5-speed automatic ETC)	✓	✓	✓	✓	
EGS 722.6 (5-speed automatic SEQ)	✓	✓			
EGS 722.9	✓	✓		✓	
ESM (Electronic Selector Module)	✓	✓		✓	
FSCU(Fuel pump)	✓	✓			
CDI 3	✓	✓			
CDI 4	✓	✓		✓	
CDI 6	✓	✓			
CDID 2	✓	✓			
CDID 3	✓	✓			

CHASSIS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ABR(Adaptive Brake)	✓	✓			
TPC(Tire Pressure Control)	✓	✓			
ADS(Adaptive damping system)	✓	✓			
ESP(Electric stability program)	✓	✓		✓	✓(SCN)

BODY	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
CGW (Central Gateway)	✓	✓			
EIS (Electronic Ignition Switch)	✓	✓			
AB (SRS / Airbag)	✓	✓			
SAM-FRONT	✓	✓	✓		
SAM-REAR	✓	✓			
OCP	✓	✓	✓	✓	
COU	✓	✓			
WSS (Weight Sensing System)	✓	✓		✓	
AHE (Trailer recognition)	✓	✓			
SVMCM		✓			
RevETR-LF	✓	✓			
RevETR-RF	✓	✓			

BODY	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
XALWA-L	✓	✓			
XALWA-R	✓	✓			
KG	✓	✓			
PSD (Control module 'Panoramic sliding roof)	✓	✓		✓	

INFO. and COMMUNICATION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ICM(Instrument Cluster)	✓	✓	✓	✓ (Service reset)	
SCM (Steering Column Module)	✓	✓	✓		
PTS (Parktronic System)	✓	✓	✓		
RFK	✓	✓			

SEATS AND DOORS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
DCM FL	✓	✓	✓	✓	
DCM FR	✓	✓	✓	✓	
DCM RL	✓	✓	✓		
DCM RR	✓	✓	✓		
ESA – Driver	✓	✓	✓		
ESA – Passenger		✓			

AIR CONDITION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
AAC (Automatic Air Conditioning)	✓	✓	✓	✓	

*SHORT TEST: Searching for all systems, clear fault code if existed in one button.

E-class, 124

DRIVE	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
LH-SFI	✓	✓	✓	✓	
HFM-SFI	✓	✓	✓	✓	✓
PMS/PEC	✓	✓			
EA / CC / ISC (with LH-SFI / HFM-SFI)	✓	✓			
DM	✓ (digital mode only)	✓		✓	
EAG 722.5 (5-speed automatic ETC)	✓ (digital mode only)	✓	✓		
BM	✓ (digital mode only)	✓		✓	
CFI/CIS		✓			
ESCM		✓			
DI		✓			
ELR (Diesel Injection)		✓			
IFI / ERE (Electronic Inline injection)	✓	✓			
EDS (Electronic Diesel System)		✓			

CHASSIS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ABS	✓	✓			
ASR	✓	✓			
ASD (Automatic Locking Differential)		✓			
4MATIC (4-Wheel Drive)		✓			

BODY	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
AB (Airbag)	✓ (digital mode only)	✓		✓ (digital mode only)	
RCL (DAS2, Code 888)		✓			
CST		✓			
ATA	✓	✓			

CLIMATE	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
CLIMATE (Air conditioning)		✓			

E-class, 210 with QUICK SERVICE & SHORT TEST

DRIVE	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
LH-SFI	✓	✓	✓	✓	
HFM-SFI	✓	✓	✓	✓	✓
PMS/PEC	✓	✓			
ME 2.0 / 2.1	✓	✓	✓	✓	✓
ME 2.8 / 2.8 AMG	✓	✓	✓	✓	
SIM4LE	✓	✓			
EA / CC / ISC (with LH-SFI / HFM-SFI)	✓	✓			
DM	✓	✓		✓	
EAG 722.5 (5-speed automatic ETC)	✓	✓	✓		
EGS 722.6 (5-speed automatic ETC)	✓	✓	✓	✓	
EGS 722.6 (5-speed automatic SEQ)	✓	✓			
ESM	✓	✓		✓	
CDI 2	✓	✓	✓		
IFI / ERE (Electronic Inline injection)	✓	✓			

CHASSIS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ABS	✓	✓			
ASR	✓	✓			
ETS	✓	✓			
ESP (Electronic Stability Program)	✓	✓			
BAS (Brake Assist System)	✓	✓			
ADS (Adaptive Damping System)		✓			
VP (Vacuum Pump Brake Booster)	✓	✓			
SPS (Speed Sensitive Power Steering)		✓			
TPC (Tire Pressure monitor)	✓	✓			

BODY	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
AB (SRS / Airbag)	✓	✓			
EIS (Electronic Ignition Switch)	✓	✓		✓	
ATA (Anti-Theft Alarm)	✓ (before 97)	✓	✓		
KFB	✓	✓			
PSE	✓	✓			
SAM	✓	✓	✓	✓	
OCP	✓	✓	✓		
LCP (Lower Control)	✓	✓	✓		
HRA		✓			
SVMCM		✓			
RCL/RFL		✓			

E-class, 210 (cont.)

INFO. and COMMUNICATION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ICM / KI (Instrument Cluster)	✓	✓		Service Reset / Oil Quality	
PTS (Parktronic System)	✓	✓			
D2B (AUDIO System)	✓	✓		✓	
CDC (CD Changer)		✓			
CTEL1 (Cellular Telephone 1)		✓			
CTEL2 (Cellular Telephone 2)		✓			
VCS		✓			
TELE AID(K-wire)		✓			
DN(K-wire)		✓			
ICS		✓			
TV (TV tuner)		✓			
APS (Auto Pilot)		✓			

SEATS AND DOORS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
DCM 1	✓	✓		✓	
DCM 2	✓	✓		✓	
DCM 3	✓	✓		✓	
DCM 4	✓	✓		✓	
ESA-FL	✓	✓			
ESA-FR	✓	✓			

AIR CONDITION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
AAC / TAC (Tempmatic Air conditioning)	✓	✓			
STH (Stationary Heater)	✓	✓			

E-class, 211-CAN with *QUICK SERVICE & *SHORT TEST

DRIVE	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ME 2.0 / 2.1	✓	✓	✓	✓	✓
ME 2.8 / 2.8 AMG	✓	✓	✓	✓	
ME 9.7	✓	✓	✓	✓	
ME 9.7 AMG	✓	✓			
MED 9.7	✓	✓			
SIM4LE	✓	✓		✓	
SIM4LSE	✓	✓		✓	
EGS 722.6 (5-speed automatic ETC)	✓	✓	✓	✓	
EGS 722.6 (5-speed automatic SEQ)	✓	✓			
EGS 722.9	✓	✓		✓	
ESM (Electronic Selector Module)	✓	✓		✓	
DTR (Distronic)		✓			
DTR (Distronic) CAN version		✓			
CDI 2	✓	✓	✓		
CDI 3	✓	✓			
CDI 4	✓	✓		✓	
CDI 5	✓	✓			
CDI D		✓			

CHASSIS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ESP (Electronic Stability Program)	✓	✓			
AIRmatic	✓	✓	✓	✓	
TPC	✓	✓			
SBC	✓	✓		✓	
ABR	✓	✓			
ENR(Electronic level control)	✓	✓		✓	

BODY	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
CGW (Central Gateway)		✓		✓	
EIS (Electronic Ignition Switch) and KG	✓	✓		✓	
AB (SRS / Airbag)	✓	✓			
SAM-Drive	✓	✓	✓	✓	
SAM-Passenger	✓	✓	✓	✓	
SAM-Rear	✓	✓	✓	✓	
OCP	✓	✓		✓	
LCP (Lower Control)	✓	✓			
UCP (Upper Control)	✓	✓			
HRA	✓	✓			
RevETR-LF		✓			
RevETR-RF		✓			
WSS (Weight Sensing System)	✓	✓		✓	
BCM (Battery control module)	✓	✓			
AHE	✓	✓			
System Diagnosis		✓			

BODY	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
XALWA-L	✓	✓			
XALWA-R	✓	✓			

INFO. and COMMUNICATION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
IC(Instrument Cluster)	✓	✓		✓	
ASSYST (Active Service System)	✓	✓			
ASSYST PLUS (PLUS Active Service System)		✓		✓	
SCM (Steering Column Module)	✓	✓			
PTS (Parktronic System)	✓	✓			
MOST – AGW	✓	✓		✓	
MOST – COMMAND / AUDIO		✓			
MOST – CDC (CD Changer)		✓			
MOST – HFS (Handsfree System and Microphone)		✓			
MOST – CTEL (Cellular Telephone)		✓			
MOST – VCS (Voice Control)		✓			
MOST – NAVI (Navigation)		✓			
MOST – SOUND (Bose SOUND System)		✓			
MOST – TV (TV Tuner)		✓			
MOST – SDAR (Satellite Radio)		✓			

SEATS AND DOORS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
DCM FL	✓	✓	✓		
DCM FR	✓	✓	✓		
DCM RL	✓	✓	✓		
DCM RR	✓	✓	✓		
ESA – Driver	✓	✓			
ESA – Passenger	✓	✓			
DS-FL (Front Left Dynamic Seat)	✓	✓			
DS-FR (Front Right Dynamic Seat)	✓	✓			
DSP (Pneumatic pump for Dynamic Seat)	✓	✓			
TLC (Trunk Lid Control)	✓	✓			
HS (Seat Heater)	✓	✓			

AIR CONDITION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
C-AAC / AAC (Automatic Air Conditioning)	✓	✓	✓	✓	
HSW	✓	✓			
STH	✓	✓			

E-class, 212-CAN with *QUICK SERVICE

DRIVE	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ME 9.7	✓	✓	✓	✓	
ME 9.7 AMG	✓	✓			
MED 9.7	✓	✓			
MED 17.7	✓	✓			
MED40	✓	✓			
EGS 722.9	✓	✓		✓	
FSCU(Fuel pump)	✓	✓			
ESM (Electronic Selector Module)	✓	✓			
ISM (Intelligent servo module)	✓	✓		✓	
SGR(Radar sensors control unit)	✓	✓			
DTR (Distrionic)	✓	✓			
DSI (DIRECT SELECT interface)	✓	✓			
SIM271(Engine)	✓	✓			
CDID 2	✓	✓			
CDID 3	✓	✓			
CDI 6	✓	✓			
SCR - Selective Catalytic Reduction	✓	✓			

CHASSIS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ESP (Electronic Stability Program)	✓	✓		✓	
AIRmatic	✓	✓			
TPM	✓	✓			

BODY	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
CGW (Central Gateway)	✓	✓			
EIS (Electronic Ignition Switch)	✓	✓			
AB (SRS / Airbag)	✓	✓			
KG	✓	✓			
SAM-Drive	✓	✓			
SAM-Rear	✓	✓			
XALWA-L	✓	✓			
XALWA-R	✓	✓			
WSS (Weight Sensing System)	✓	✓		✓	
OCP	✓	✓		✓	
RevETR-LF	✓	✓			
RevETR-RF	✓	✓			
PSD(Panoramic sliding roof)	✓	✓		✓	
AHE		✓			
KDS(Trunk lid control)	✓	✓			
SG-FOND(Rear control unit)	✓	✓			
SVMCM		✓			

INFO. and COMMUNICATION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
IC(Instrument Cluster)	✓	✓		OIL RESET	
SCM (Steering Column Module)	✓	✓			
DSI(DIRECT SELECT interface)		✓			
PTS (Parktronic System)	✓	✓			
MFK(Multifunction camera)	✓	✓			
NSA(Night View Assist)	✓	✓			
MOST – UCI(Media interface)	✓	✓			
MOST – COMMAND	✓	✓			
MOST – ZBE[COU](Audio/COMAND operating unit)	✓	✓			
MOST – ZAN(Audio/COMAND display)	✓	✓			
MOST – DAB(Digital Audio Broadcasting)		✓			
MOST – SDAR(Satellite digital audio radio)		✓			
MOST – SOUND (SOUND System)		✓			
MOST – TV (TV Tuner)		✓			
MOST – DTA(TELEAID)		✓			
MOST – DTA (TELEAID) - Emergency call		✓			
MOST – DTA (TELEAID) - MB Info / Breakdown assistance		✓			
MOST – DTA (TELEAID) - Stolen vehicle tracking		✓			
MOST – DTA (TELEAID) - Vehicle remote unlocking/locking		✓			
SEATS AND DOORS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
DCM FL	✓	✓	✓		
DCM FR	✓	✓	✓		
DCM RL	✓	✓	✓		
DCM RR	✓	✓	✓		
ESA – Driver	✓	✓			
ESA – Passenger	✓	✓			
AMKS-LF– Active multicontour seat (Driver)	✓	✓			
AMKS-RF - Active multicontour seat (Passenger)	✓	✓			
PPAMKS - Pneumatic pump for active multicontour seat	✓	✓			
AIR CONDITION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
C-AAC / AAC (Automatic Air Conditioning)	✓	✓		✓	
LRH[HSW] (Heated steering wheel)		✓			

E-class(Coupe), 207-CAN with *QUICK SERVICE

DRIVE	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ME 9.7	✓	✓	✓	✓	
ME 9.7 AMG	✓	✓			
MED 9.7	✓	✓			
MED 17.7	✓	✓			
EGS 722.9	✓	✓		✓	
FSCU(Fuel pump)	✓	✓			
ESM (Electronic Selector Module)	✓	✓			
SGR(Radar sensors control unit)	✓	✓			
DTR (Distronic)	✓	✓			
SIM271(Engine)	✓	✓			
CDID 2	✓	✓			
CDID 3	✓	✓			
CDI 6	✓	✓			

CHASSIS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ESP (Electronic Stability Program)	✓	✓		✓	
ADS (Adaptive damping system)	✓	✓			
TPC	✓	✓			

BODY	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
CGW (Central Gateway)	✓	✓			
EIS (Electronic Ignition Switch)	✓	✓			
AB (SRS / Airbag)	✓	✓			
KG	✓	✓			
SAM-Drive	✓	✓			
SAM-Rear	✓	✓			
XALWA-L	✓	✓			
XALWA-R	✓	✓			
WSS (Weight Sensing System)	✓	✓		✓	
OCP	✓	✓		✓	
RevETR-LF	✓	✓			
RevETR-RF	✓	✓			

BODY	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
AHE	✓	✓			
SVMCM	✓	✓			
SG-FOND(Rear control unit)		✓			

INFO. and COMMUNICATION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
IC(Instrument Cluster)	✓	✓		OIL RESET	
SCM (Steering Column Module)	✓	✓			
PTS (Parktronic System)	✓	✓			
MFK(Multifunction camera)	✓	✓			
MOST – UCI(Media interface)	✓	✓			
MOST – COMMAND	✓	✓			
MOST – ZBE[COU](Audio/COMAND operating unit)	✓	✓			
MOST – ZAN(Audio/COMAND display)	✓	✓			
MOST – DAB(Digital Audio Broadcasting)		✓			
MOST – SDAR(Satellite digital audio radio)		✓			
MOST – SOUND (SOUND System)		✓			
MOST – TV (TV Tuner)		✓			
MOST – DTA(TELEAID)		✓			
MOST – DTA (TELEAID) - Emergency call		✓			
MOST – DTA (TELEAID) - MB Info / Breakdown assistance		✓			
MOST – DTA (TELEAID) - Stolen vehicle tracking		✓			
MOST – DTA (TELEAID) - Vehicle remote unlocking/locking		✓			

SEATS AND DOORS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
DCM L	✓	✓	✓		
DCM R	✓	✓	✓		
ESA – Driver	✓	✓			
ESA – Passenger	✓	✓			

AIR CONDITION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
C-AAC / AAC (Automatic Air Conditioning)	✓	✓		✓	

S-class, 126

SYSTEM	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
Engine ESCM		✓			
Engine CFI		✓			
ELR (Diesel Injection Electronic ISC)		✓			
EDS (Electronic Diesel System)		✓			
ASD (Automatic Locking Differential)		✓			
AB (SRS / Airbag)	✓ (digital mode only)	✓		✓ (digital mode only)	
Climate Control		✓			

S-class, 140 with SHORT TEST

DRIVE	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
LH-SFI / LH-SFI LEFT	✓	✓	✓	✓	
LH-SFI RIGHT	✓	✓	✓	✓	
HFM-SFI	✓	✓	✓	✓	✓
ME 1.0 LEFT BANK	✓	✓	✓	✓	✓
ME 1.0 RIGHT BANK	✓	✓	✓	✓	✓
ME 1.0 V8	✓	✓	✓	✓	✓
ME 2.0 / 2.1	✓	✓	✓	✓	✓
EA / CC / ISC (with LH-SFI / HFM-SFI)	✓	✓			
DM	✓	✓		✓	
BM	✓	✓			
EAG 722.5 (5-speed automatic ETC)	✓	✓	✓		
EGS 722.6 (5-speed automatic ETC)	✓	✓	✓	✓	
IFI / ERE (Electronic Inline injection)	✓	✓			
DI		✓			
EDS		✓			

CHASSIS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ABS	✓	✓			
ASR	✓	✓			
ETS	✓	✓			
ESP (Electronic Stability Program)	✓	✓			
BAS (Brake Assist System)	✓	✓			
SPS (Speed Sensitive Power-Steering)		✓			
ASD (Automatic Locking Differential)		✓			
ADS (Adaptive Damping System)		✓			

S-class, 140 with SHORT TEST (continued)

BODY	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
AB (SRS / Airbag)	✓	✓			
IC (Instrument Cluster)	✓	✓		✓	
ATA (Anti-Thief Alarm)	✓	✓			
IRC(IR Controller)		✓			
RCL(DAS1/X)		✓			
RFL(DAS2/X)		✓			
CF/KFB		✓			
PSE	✓	✓			
HRA	✓	✓			
PTS	✓	✓			

AIR CONDITION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
AAC / HAU (Automatic Air conditioning)	✓	✓			
STH (Stationary Heater)	✓	✓			

S-class, 221-CAN with *QUICK SERVICE & *SHORT TEST

DRIVE	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ME 9.7	✓	✓	✓	✓	
MED9.7	✓	✓			
EGS 722.9	✓	✓		✓	
ISM (Intelligent servo module)	✓	✓	✓		
DTR (Distronic)		✓			
SGR (Radar sensors control unit)	✓	✓			
CDI 4	✓	✓		✓	
CDI 5	✓	✓			
CDI 6	✓	✓			
CDID 3	✓	✓			
ME 2.7.2 (V12)	✓	✓			
ME 17.7	✓	✓			
MED 17.7	✓	✓			

CHASSIS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ABR (Adaptive Brake)	✓	✓		✓(SCN)	
AIRmatic (Suspension)	✓	✓	✓		
EPB (Electronic parking brake)	✓	✓			
TPC (Tire Pressure)	✓	✓			

RBS (Regenerative braking system)	✓	✓			
EHPS (Electrohydraulic Power Steering)		✓			

BODY	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
CGW (Central Gateway)		✓			
EIS (Electronic Ignition Switch)	✓	✓			
AB (SRS / Airbag)	✓	✓			
WSS (Weight sensing system)	✓	✓			
RevETR-LF (Left front reversible emergency tensioning retractor)	✓	✓			
RevETR-RF (Right front reversible emergency tensioning retractor)	✓	✓			
XALWA-L (Left headlamp)	✓	✓			
XALWA-R (Right headlamp)	✓	✓			
KG (keyless Go)	✓	✓			
SAM-Driver	✓	✓		✓	
SAM-REAR	✓	✓		✓	
PSE (Pneumatic system)		✓			
OCP	✓	✓			
UCP (Upper Control)	✓	✓			
COU – ZBE (Central operating unit)	✓	✓			
HBF (Rear control field / panel)		✓			
System Diagnosis		✓			
BNS (Vehicle power supply control module)	✓	✓			
AHE (Trailer recognition)		✓			
SVMCM		✓			
PSD - Panoramic sliding roof		✓			
SG-BMS - Battery management system		✓			
SG-DDW - DC/DC converter control unit		✓			

S-class, 221-CAN with *QUICK SERVICE & *SHORT TEST (continued)

SEATS AND DOORS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
DCM FL	✓	✓	✓		
DCM FR	✓	✓	✓		
DCM RL	✓	✓	✓		
DCM RR	✓	✓	✓		
ESA – Driver	✓	✓			
ESA – Passenger	✓	✓			
ESA – R	✓	✓			
DS-FL (Front Left Dynamic Seat)		✓			
DS-FR (Front Right Dynamic Seat)		✓			
DSP (Pneumatic pump for Dynamic Seat)		✓			
MKL-HL (Rear left Multicontour backrest)		✓			
MKL-HR (Rear right Multicontour backrest)		✓			
TLC (Truck lid control)	✓	✓			

INFO. and COMMUNICATION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ICM (Instrument Cluster)	✓	✓			
ASSYST (Active Service System)	✓	✓			
ASSYST PLUS (PLUS Active Service System)		✓		✓	
NSA (Night View Assist)	✓	✓			
SCM (Steering Column Module)	✓	✓			
PTS (Parktronic System)	✓	✓			
RFK (Backup camera)	✓	✓			
COMAND		✓			
ZAN (Central Display)		✓			
TELE-AID		✓			

AIR CONDITION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
AAC (Automatic Air Conditioning)	✓	✓	✓	✓	
KBE-H (Rear A/C operating unit)	✓	✓			
STH (Stationary Heater)		✓			

S-class, 220-CAN with *QUICK SERVICE & *SHORT TEST

DRIVE	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ME 2.8 / 2.8 AMG	✓	✓	✓	✓	
ME 2.7	✓	✓			
ME 9.7	✓	✓	✓	✓	
EGS 722.6 (5-speed automatic ETC)	✓	✓	✓	✓	
EGS 722.6 (5-speed automatic SEQ)	✓	✓			
EGS 722.9	✓	✓		✓	
ESM (Electronic Selector Module)	✓	✓		✓	
DTR (Distronic)		✓			
CDI 2	✓	✓	✓		
CDI 3	✓	✓			
CDI 4	✓	✓		✓	

CHASSIS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ESP (Electronic Stability Program)	✓	✓			
AIRmatic (Suspension)	✓	✓	✓	✓	
ABC (Active Body Control)	✓	✓	✓	✓	
TPC (Tire Pressure)	✓	✓			

S-class, 220-CAN with *QUICK SERVICE & *SHORT TEST (continued)

BODY	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
CGW (Central Gateway)		✓		✓	
EIS (Electronic Ignition Switch)	✓	✓		✓	
AB (SRS / Airbag)	✓	✓			
RevETR-LF (Left front reversible emergency tensioning retractor)	✓	✓			
RevETR-RF (Right front reversible emergency tensioning retractor)	✓	✓			
HRA	✓	✓			
HLCM-L (Left headlamp)	✓	✓			
HLCM-R (Right headlamp)	✓	✓			
KG (keyless Go)	✓	✓			
SAM-FRONT LEFT	✓	✓		✓	
SAM-FRONT RIGHT	✓	✓			
SAM-REAR	✓	✓		✓	
PSE (Pneumatic system)	✓	✓		✓	
OCP	✓	✓			
UCP (Upper Control)	✓	✓			
System Diagnosis		✓			
AHE (Trailer recognition)		✓			
SVMCM		✓			

SEATS AND DOORS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
DCM FL	✓	✓	✓		
DCM FR	✓	✓	✓		
DCM RL	✓	✓	✓		
DCM RR	✓	✓	✓		
ESA – Driver	✓	✓			
ESA – Passenger	✓	✓			
ESA – R	✓	✓			
DS-FL (Front Left Dynamic Seat)	✓	✓			
DS-FR (Front Right Dynamic Seat)	✓	✓			
DSP (Pneumatic pump for Dynamic Seat)	✓	✓			
OSB-FL (Multicontour backrest front left)	✓	✓			
OSB-FR (Multicontour backrest front Right)	✓	✓			
OSB-R (Multicontour backrest rear)	✓	✓			

S-class, 220-CAN with *QUICK SERVICE & *SHORT TEST (continued)

INFO. and COMMUNICATION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ICM(Instrument Cluster)	✓	✓		Service Reset / Oil Quality	
SCM (Steering Column Module)	✓	✓			
PTS (Parktronic System)	✓	✓			
MOST – AGW	✓	✓		✓	
MOST – COMMAND / AUDIO		✓			
MOST – CDC (CD Changer)		✓			
MOST – HFS (Handsfree System and Microphone)		✓			
MOST – CTEL (Cellular Telephone)		✓			
MOST – VCS (Voice Control)		✓			
MOST – NAVI (Navigation)		✓			
MOST – SOUND (Bose SOUND System)		✓			
MOST – TV (TV Tuner)		✓			
MOST – SDAR (Satellite Radio)		✓			
D2B	✓	✓		✓	
D2B – CDC (CD Changer)		✓			
D2B – CTEL1 (Cellular Telephone)		✓			
D2B – CTEL2 (Cellular Telephone)		✓			
D2B – VCS (Voice Control)		✓			
D2B – SOUND (Bose SOUND System)		✓			
D2B – TV (TV Tuner)		✓			
D2B – DN		✓			

AIR CONDITION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
AAC (Automatic Air Conditioning)	✓	✓	✓	✓	
KLA (Climate Control)	✓	✓	✓		
REAR AC	✓	✓			
STH (Stationary Heater)	✓	✓			
HSW (Heated Steering Wheel)	✓	✓			

S-class, 220 (non-CAN) with *QUICK SERVICE & *SHORT TEST

DRIVE	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ME 1.0	✓	✓	✓	✓	✓
ME 2.0 / 2.0 V8	✓	✓	✓	✓	✓
ME 2.8 / 2.8 AMG	✓	✓	✓	✓	
ME 2.7	✓	✓			
EGS 722.6 (5-speed automatic ETC)	✓	✓	✓	✓	
EGS 722.6 (5-speed automatic SEQ)	✓	✓			
ESM (Electronic Selector Module)	✓	✓		✓	
DTR (Distronic)		✓			
CDI 2	✓	✓	✓		

CHASSIS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ESP (Electronic Stability Program)	✓	✓			
AIRmatic (Suspension)	✓	✓	✓	✓	
ABC (Active Body Control)	✓	✓	✓	✓	
TPC (Tire Pressure)	✓	✓			

BODY	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
EIS (Electronic Ignition Switch)	✓	✓			
AB (SRS / Airbag)	✓	✓			
HRA	✓	✓			
KG (keyless Go)	✓	✓			
SAM-FRONT LEFT	✓	✓		✓	
SAM-FRONT RIGHT	✓	✓			
SAM-REAR	✓	✓		✓	
PSE (Pneumatic system)	✓	✓		✓	
OCP	✓	✓			
UCP (Upper Control)	✓	✓			
AHE (Trailer recognition)		✓			
SVMCM		✓			

S-class, 220 (non-CAN) with *QUICK SERVICE & *SHORT TEST (continued)

SEATS AND DOORS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
DCM FL	✓	✓	✓		
DCM FR	✓	✓	✓		
DCM RL	✓	✓	✓		
DCM RR	✓	✓	✓		
ESA – Driver	✓	✓			
ESA – Passenger	✓	✓			
ESA – R	✓	✓			
OSB-FL (Multicontour backrest front left)	✓	✓			
OSB-FR (Multicontour backrest front Right)	✓	✓			
OSB-R (Multicontour backrest rear)	✓	✓			

INFO. and COMMUNICATION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ICM(Instrument Cluster)	✓	✓		Service Reset / Oil Quality	
SCM (Steering Column Module)	✓	✓			
PTS (Parktronic System)	✓	✓			
D2B	✓	✓		✓	
D2B – CDC (CD Changer)		✓			
D2B – CTEL1 (Cellular Telephone)		✓			
D2B – CTEL2 (Cellular Telephone)		✓			
D2B – VCS (Voice Control)		✓			
D2B – SOUND (Bose SOUND System)		✓			
D2B – TV (TV Tuner)		✓			
D2B – DN		✓			

AIR CONDITION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
AAC (Automatic Air Conditioning)	✓	✓	✓	✓	
KLA (Climate Control)	✓	✓	✓		
REAR AC	✓	✓			
STH (Stationary Heater)	✓	✓			
HSW (Heated Steering Wheel)	✓	✓			
TSTH (Radio Remote Control STH)		✓			

SLK-class, 170

DRIVE	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
HFM-SFI	✓	✓	✓	✓	✓
PMS/PEC	✓	✓			
ME 2.0 / 2.1	✓	✓	✓	✓	✓
SIM4LE	✓	✓			
EAG 722.5 (5-speed automatic ETC)	✓	✓	✓		
EGS 722.6 (5-speed automatic ETC)	✓	✓	✓	✓	
EGS 722.6 (5-speed automatic SEQ)	✓	✓			
ESM	✓	✓		✓	

CHASSIS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ABS	✓	✓			
ASR	✓	✓			
ETS	✓	✓			
ESP (Electronic Stability Program)	✓	✓			
BAS (Brake Assist System)	✓	✓			
VP (Vacuum Pump Brake Booster)	✓	✓			

BODY	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
AB (SRS / Airbag)	✓	✓			
ATA (Anti-Thief Alarm)	✓	✓			
RFL		✓			
RFL / DAS2		✓			
HRA		✓			
VR	✓	✓	✓		
PSE	✓	✓			
CCM	✓	✓			

INFO. and COMMUNICATION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ICM / KI (Instrument Cluster)	✓	✓		Service Reset / Oil Quality	
D2B (AUDIO System)	✓	✓		✓	
CDC (CD Changer)		✓			
CTEL1 (Cellular Telephone 1)		✓			
CTEL2 (Cellular Telephone 2)		✓			
VCS		✓			
TELE AID(K-wire)		✓			

SLK-class, 170 (continued)

AIR CONDITION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
AAC / TAC (Tempmatic Air conditioning)	✓	✓			

SLK-class, 171-CAN

DRIVE	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ME 2.8 / 2.8 AMG	✓	✓	✓	✓	
ME 9.7	✓	✓	✓	✓	
SIM4LE	✓	✓			
EGS 722.6 (5-speed automatic ETC)	✓	✓	✓	✓	
EGS 722.6 (5-speed automatic SEQ)	✓	✓			
EGS 722.9	✓	✓		✓	
ESM (Electronic Selector Module)	✓	✓		✓	

CHASSIS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ESP (Electronic Stability Program)	✓	✓		✓	

BODY	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
CGW (Central Gateway)		✓			
EIS (Electronic Ignition Switch) / KG (Keyless)	✓	✓			
AB (SRS / Airbag)	✓	✓			
VR	✓	✓			
HRA		✓			
OCP	✓	✓			
UCP (Upper Control)	✓	✓			
SAM-FRONT	✓	✓			
SAM-REAR	✓	✓			
System Diagnosis		✓			

SLK-class, 171-CAN (continued)

INFO. and COMMUNICATION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
IC(Instrument Cluster)		✓			
ASSYST (Active Service System)	✓	✓		✓	
ASSYST PLUS (PLUS Active Service System)		✓		✓(Service Reset)	
SCM (Steering Column Module)		✓			
PTS (Parktronic System)		✓			
MOST – AGW	✓	✓		✓	
MOST – COMMAND / AUDIO		✓			
MOST – CDC (CD Changer)		✓			
MOST – HFS (Handsfree System and Microphone)		✓			
MOST – CTEL (Cellular Telephone)		✓			
MOST – VCS (Voice Control)		✓			
MOST – NAVI (Navigation)		✓			
MOST – SOUND (Bose SOUND System)		✓			
MOST – TV (TV Tuner)		✓			
MOST – SDAR (Satellite Radio)		✓			

SEATS AND DOORS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
DCM LEFT	✓	✓	✓		
DCM RIGHT	✓	✓	✓		
ESA – Driver	✓	✓			
ESA – Passenger	✓	✓			
HS (Seat heater)	✓	✓			

AIR CONDITION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
C-AAC / AAC (Automatic Air Conditioning)	✓	✓	✓	✓	

SLK-class, 172 with *QUICK SERVICE

DRIVE	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
SIM271(Engine)	✓	✓			
MED 17.7	✓	✓			
MED40	✓	✓			
EGS 722.9	✓	✓		✓	
FSCU(Fuel pump)	✓	✓			
ESM (Electronic Selector Module)	✓	✓			
SGR(Radar sensors control unit)	✓	✓			
DTR (Distronic)	✓	✓			
CDID 2	✓	✓			
CDID 3	✓	✓			

CHASSIS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ESP (Electronic Stability Program)	✓	✓		✓	
ADS (Adaptive damping system)	✓	✓			
TPM	✓	✓			
EPB (Electronic parking brake)	✓	✓	✓		

BODY	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
CGW (Central Gateway)	✓	✓			
EIS (Electronic Ignition Switch)	✓	✓			
AB (SRS / Airbag)		✓			
KG	✓	✓			
SAM-Drive	✓	✓			
SAM-Rear	✓	✓			
RevETR-LF	✓	✓			
RevETR-RF	✓	✓			
AIRSCARF		✓			
SG-SW (Headlamp)		✓			
VDS (Vario roof)		✓			

INFO. and COMMUNICATION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
IC(Instrument Cluster)	✓	✓		OIL RESET	
SCM (Steering Column Module)	✓	✓			
PTS (Parktronic System)	✓	✓			
MFK(Multifunction camera)	✓	✓			
MOST – UCI(Media interface)	✓	✓			
MOST – COMMAND	✓	✓			
MOST – ZBE[COU](Audio/COMAND operating unit)	✓	✓			
MOST – ZAN(Audio/COMAND display)	✓	✓			
MOST – DAB(Digital Audio Broadcasting)		✓			
MOST – SDAR(Satellite digital audio radio)		✓			
MOST – SOUND (SOUND System)		✓			
MOST – TV (TV Tuner)		✓			
MOST – DTA(TELEAID)		✓			
MOST – DTA (TELEAID) - Emergency call		✓			
MOST – DTA (TELEAID) - MB Info / Breakdown assistance		✓			
MOST – DTA (TELEAID) - Stolen vehicle tracking		✓			
MOST – DTA (TELEAID) - Vehicle remote unlocking/locking		✓			
SEATS AND DOORS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
DCM FL	✓	✓	✓		
DCM FR	✓	✓	✓		
ESA – Driver		✓			
ESA – Passenger		✓			
AIR CONDITION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
C-AAC / AAC (Automatic Air Conditioning)		✓		✓	

CLK-class, 208

DRIVE	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ME 2.0 / 2.1	✓	✓	✓	✓	✓
SIM4LE	✓	✓			
EAG 722.5 (5-speed automatic ETC)	✓	✓	✓		
EGS 722.6 (5-speed automatic ETC)	✓	✓	✓	✓	
EGS 722.6 (5-speed automatic SEQ)	✓	✓			
ESM	✓	✓		✓	
DTR		✓			
CDI 2	✓	✓	✓		

CHASSIS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ESP (Electronic Stability Program)	✓	✓			

BODY	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
AB (SRS / Airbag)	✓	✓			
EIS (Electronic Ignition Switch)	✓	✓		✓	
HRA-FL	✓ (partial)	✓			
HRA-FR	✓ (partial)	✓			
UCP	✓	✓			
LCP (Lower Control)		✓			
SAM-FRONT	✓	✓		✓	
SAM-REAR	✓	✓		✓	
AHE (Trailer recognition)		✓			
RVC(Rollover bar soft top control module)	✓	✓	✓		

INFO. and COMMUNICATION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ICM / KI (Instrument Cluster)	✓	✓		Service Reset / Oil Quality	
SCM	✓	✓			
PTS (Parktronic System)	✓	✓			
D2B (AUDIO System)	✓	✓		✓	
CDC (CD Changer)		✓			
CTEL1 (Cellular Telephone 1)		✓			
CTEL2 (Cellular Telephone 2)		✓			
VCS		✓			
TV (TV tuner)		✓			
SOUND		✓			

CLK-class, 208 (continued)

SEATS AND DOORS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
DCM LEFT	✓	✓			
DCM RIGHT	✓	✓			
DCM REAR		✓			
ESA LEFT	✓	✓			
ESA RIGHT	✓	✓			
TLC		✓			

AIR CONDITION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
C-AAC / AAC (Automatic Air conditioning)	✓	✓			
STH (Stationary Heater)	✓	✓			

CLK-class, 209

DRIVE	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ME 2.0 / 2.1	✓	✓	✓	✓	✓
SIM4LE	✓	✓			
EAG 722.5 (5-speed automatic ETC)	✓	✓	✓		
EGS 722.6 (5-speed automatic ETC)	✓	✓	✓	✓	
EGS 722.6 (5-speed automatic SEQ)	✓	✓			
ESM	✓	✓		✓	
DTR		✓			
CDI 2	✓	✓	✓		

CHASSIS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ESP (Electronic Stability Program)	✓	✓		✓	

BODY	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
AB (SRS / Airbag)	✓	✓			
EIS (Electronic Ignition Switch)	✓	✓		✓	
HRA-FL	✓	✓			
HRA-FR	✓	✓			
OCP	✓	✓			
UCP	✓	✓			
LCP (Lower Control)	✓	✓			
SAM-FRONT	✓	✓		✓	
SAM-REAR	✓	✓		✓	
AHE (Trailer recognition)		✓			
RVC	✓	✓			

CLK-class, 209 (continued)

INFO. and COMMUNICATION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ICM / KI (Instrument Cluster)	✓	✓		Service Reset / Oil Quality	
SCM	✓	✓			
PTS (Parktronic System)	✓	✓			
D2B (AUDIO System)	✓	✓		✓	
CDC (CD Changer)		✓			
CTEL1 (Cellular Telephone 1)		✓			
CTEL2 (Cellular Telephone 2)		✓			
VCS		✓			
TV (TV tuner)		✓			
SOUND		✓			

SEATS AND DOORS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
DCM LEFT	✓	✓			
DCM RIGHT	✓	✓			
DCM REAR		✓			
ESA LEFT	✓	✓			
ESA RIGHT	✓	✓			
TLC		✓			

AIR CONDITION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
C-AAC / AAC (Automatic Air conditioning)	✓	✓	✓ (partial version)	✓ (partial version)	
STH (Stationary Heater) (non-CAN)	✓	✓			

SL-class, 107

SYSTEM	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ENGINE-CFI		✓			
AB (SRS / Airbag)	✓ (digital mode only)	✓		✓ (digital mode only)	

SL-class, 129

DRIVE	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
LH-SFI	✓	✓	✓	✓	
HFM-SFI	✓	✓	✓	✓	✓
PMS/PEC	✓	✓			
ME 2.0 / 2.1	✓	✓	✓	✓	✓
BM	✓	✓			
EA / CC / ISC (with LH-SFI / HFM-SFI)	✓	✓			
DM	✓	✓		✓	
EAG 722.5 (5-speed automatic ETC)	✓	✓	✓		
EGS 722.6 (5-speed automatic ETC)	✓	✓	✓	✓	
EGS 722.6 (5-speed automatic SEQ)	✓	✓			
CFI		✓			
DI		✓			
CDI 2	✓	✓			
IFI / ERE (Electronic Inline injection)	✓	✓			

CHASSIS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ABS	✓	✓			
ASR	✓	✓			
ETS	✓	✓			
ESP (Electronic Stability Program)	✓	✓			
BAS (Brake Assist System)	✓	✓			
ADS (Adaptive Damping System)		✓			
ASD (Automatic Locking Differential)		✓			

BODY	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
AB (SRS / Airbag)	✓	✓			
IR (IR controller)		✓			
ATA (Anti-Thief Alarm)	✓ (before 97)	✓			
RFL		✓			
RCL (DAS2/X)		✓			
APS		✓			
RB		✓			
RST		✓			
HRA		✓			

SL-class, 129

INFO. and COMMUNICATION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ICM / KI (Instrument Cluster)	✓	✓		Service Reset / Oil Quality	
PTS (Parktronic System)	✓	✓			
D2B (AUDIO System)	✓	✓		✓	
CTEL1 (Cellular Telephone 1)		✓			
VCS		✓			
TELE AID(K-wire)		✓			
DN(K-wire)		✓			

AIR CONDITION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
AAC / HAC (Automatic Air conditioning)	✓	✓			
STH (Stationary Heater)	✓	✓			

SL-class, 230

DRIVE	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ME 1.0	✓	✓	✓	✓	✓
ME 2.0 / 2.0 V8	✓	✓	✓	✓	✓
ME 2.8 / 2.8 AMG	✓	✓	✓	✓	
EGS 722.6 (5-speed automatic ETC)	✓	✓	✓	✓	
ESM (Electronic Selector Module)	✓	✓		✓	
DTR (Distronic)		✓			

CHASSIS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ESP (Electronic Stability Program)	✓	✓			
SBC	✓	✓		✓	
ABC (Active Body Control)	✓	✓	✓	✓	
TPC (Tire Pressure)	✓	✓			

SEATS AND DOORS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
DCM LEFT	✓	✓	✓		
DCM RIGHT	✓	✓	✓		
ESA – LEFT	✓	✓			
ESA – RIGHT	✓	✓			
OSB-FL (Multicontour backrest Left)	✓	✓			
OSB-FR (Multicontour backrest Right)	✓	✓			

SL-class, 230 (continued)

BODY	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
EIS (Electronic Ignition Switch)	✓	✓			
AB (SRS / Airbag)	✓	✓			
HRA-Front Right		✓			
HRA-Front Left		✓			
KG (keyless Go)	✓	✓			
SAM-Driver Side	✓	✓		✓	
SAM-Passenger Side	✓	✓			
SAM-Rear	✓	✓		✓	
PSE	✓	✓			
OCP	✓	✓			
LCP (Lower Control)	✓	✓	✓		
BNS (Vehicle power supply module)		✓			
RVC (Rollover bar / Vario Roof)	✓	✓	✓		
System Diagnosis		✓			

INFO. and COMMUNICATION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ICM(Instrument Cluster)	✓	✓		✓	
SCM (Steering Column Module)	✓	✓			
PTS (Parktronic System)	✓	✓			
D2B	✓	✓		✓	
D2B – CDC (CD Changer)		✓			
D2B – CTEL1 (Cellular Telephone)		✓			
D2B – CTEL2 (Cellular Telephone)		✓			
D2B – VCS (Voice Control)		✓			
D2B – SOUND (Bose SOUND System)		✓			
D2B – TELE AID		✓			
D2B – TV (TV Tuner)		✓			

AIR CONDITION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
AAC (Automatic Air Conditioning)	✓	✓			
STH (Stationary Heater)	✓	✓			

SL-class, 230-CAN

DRIVE	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ME 9.7	✓	✓	✓	✓	
ME 2.8 / 2.8 AMG	✓	✓	✓	✓	
EGS 722.6 (5-speed automatic ETC)	✓	✓	✓	✓	
ESM (Electronic Selector Module)	✓	✓		✓	
DTR (Distronic)		✓			

CHASSIS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ESP (Electronic Stability Program)		✓			
SBC	✓	✓	✓		
ABC (Active Body Control)		✓			✓
TPC (Tire Pressure)		✓			

SEATS AND DOORS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
DCM LEFT	✓	✓	✓		
DCM RIGHT	✓	✓	✓		
ESA – LEFT	✓	✓			
ESA – RIGHT	✓	✓			
OSB-FL (Multicontour backrest Left)	✓	✓			
OSB-FR (Multicontour backrest Right)	✓	✓			

SL-class, 230-CAN(continued)

BODY	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
CGW		✓			
WSS	✓	✓		✓	
EIS (Electronic Ignition Switch)	✓	✓			
AB (SRS / Airbag)		✓			
HRA-Front Right		✓			
HRA-Front Left		✓			
KG (keyless Go)		✓			
SAM-Driver Side	✓	✓		✓	
SAM-Passenger Side	✓	✓			
SAM-Rear	✓	✓		✓	
PSE	✓	✓			
OCP	✓	✓			
LCP (Lower Control)	✓	✓	✓		
BNS (Vehicle power supply module)		✓			
RVC (Rollover bar / Vario Roof)	✓	✓	✓		
System Diagnosis		✓			

INFO. and COMMUNICATION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ICM(Instrument Cluster)	✓	✓		✓	
SCM (Steering Column Module)	✓	✓			
PTS (Parktronic System)	✓	✓			
D2B	✓	✓		✓	
D2B – CDC (CD Changer)		✓			
D2B – CTEL1 (Cellular Telephone)		✓			
D2B – CTEL2 (Cellular Telephone)		✓			
D2B – VCS (Voice Control)		✓			
D2B – SOUND (Bose SOUND System)		✓			
D2B – TELE AID		✓			
D2B – TV (TV Tuner)		✓			

AIR CONDITION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
AAC (Automatic Air Conditioning)	✓	✓			
STH (Stationary Heater)	✓	✓			

SL-class, 231 with *QUICK SERVICE

DRIVE	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
MED 17.7	✓	✓			
EGS 722.9	✓	✓			
DCT	✓	✓			
FSCU (Fuel pump)	✓	✓			
SGR (Radar sensors control unit)	✓	✓			
DTR (Distronic)	✓	✓			
ISM (Intelligent servo module)	✓	✓		✓	

CHASSIS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ESP (Electronic Stability Program)	✓	✓			
EPB (Electronic parking brake)	✓	✓			
ABC (Active Body Control)	✓	✓			
AIRmatic	✓	✓			
EPS(Electrical power steering)	✓	✓			
TPC(Tire Pressure Control)	✓	✓			

BODY	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
CGW (Central Gateway)		✓			
AB (SRS / Airbag)	✓	✓			
EIS (Electronic Ignition Switch)	✓	✓			
KG (Keyless Go)	✓	✓			
SAM-FRONT	✓	✓	✓		
SAM-REAR	✓	✓			
RevETR-LF	✓	✓			
RevETR-RF	✓	✓			
VDS (Vario roof control)	✓	✓			
PSD(Panoramic sliding roof)	✓	✓			
AIRSCARF	✓	✓			
MSC (MAGIC SKY CONTROL)	✓	✓	✓		
SGSW(Headlamp)		✓			

INFO. and COMMUNICATION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ICM(Instrument Cluster)	✓	✓	✓	✓ (Service reset)	
SCM (Steering Column Module)	✓	✓	✓		
PTS (Parktronic System)	✓	✓			
MFK(Multifunction camera)	✓	✓			
RFK (Backup camera)	✓	✓			

NSA (Night View Assist)	✓	✓			
-------------------------	---	---	--	--	--

SEATS AND DOORS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
DCM FL	✓	✓	✓		
DCM FR	✓	✓	✓		
DCM RL	✓	✓	✓		
DCM RR	✓	✓	✓		
ESA – Driver	✓	✓			
ESA – Passenger	✓	✓			
or active multicontour seat)	✓	✓			
AMKS LF (Active multicontour seat (Driver))	✓	✓			
AMKS RF (Active multicontour seat (Passenger))	✓	✓			

AIR CONDITION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
AAC (Automatic Air Conditioning)	✓	✓			

SLR-class, 199 with *QUICK SERVICE

DRIVE	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ME 1.0	✓	✓	✓	✓	✓
ME 2.0 / 2.0 V8	✓	✓	✓	✓	✓
ME 2.8 / 2.8 AMG	✓	✓	✓	✓	
EGS 722.6 (5-speed automatic ETC)	✓	✓	✓	✓	
ESM (Electronic Selector Module)	✓	✓		✓	
DTR (Distronic)		✓			

CHASSIS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ESP (Electronic Stability Program)	✓	✓			
SBC	✓	✓		✓	
ABC (Active Body Control)	✓	✓	✓	✓	
TPC (Tire Pressure)	✓	✓			

SEATS AND DOORS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
DCM LEFT	✓	✓	✓		
DCM RIGHT	✓	✓	✓		
ESA – LEFT	✓	✓			
ESA – RIGHT	✓	✓			

Specification

OSB-FL (Multicontour backrest Left)	✓	✓			
OSB-FR (Multicontour backrest Right)	✓	✓			

SLR-class, 199 (continued)

BODY	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
EIS (Electronic Ignition Switch)	✓	✓			
AB (SRS / Airbag)	✓	✓			
HRA-Front Right		✓			
HRA-Front Left		✓			
KG (keyless Go)	✓	✓			
SAM-Driver Side	✓	✓		✓	
SAM-Passenger Side	✓	✓			
SAM-Rear	✓	✓		✓	
PSE	✓	✓			
OCP	✓	✓			
LCP (Lower Control)	✓	✓	✓		
BNS (Vehicle power supply module)		✓			
RVC (Rollover bar / Vario Roof)	✓	✓	✓		
System Diagnosis		✓			

INFO. and COMMUNICATION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ICM(Instrument Cluster)	✓	✓		✓	
SCM (Steering Column Module)	✓	✓			
PTS (Parktronic System)	✓	✓			
D2B	✓	✓		✓	
D2B – CDC (CD Changer)		✓			
D2B – CTEL1 (Cellular Telephone)		✓			
D2B – CTEL2 (Cellular Telephone)		✓			
D2B – VCS (Voice Control)		✓			
D2B – SOUND (Bose SOUND System)		✓			
D2B – TELE AID		✓			
D2B – TV (TV Tuner)		✓			

AIR CONDITION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
AAC (Automatic Air Conditioning)	✓	✓			
STH (Stationary Heater)	✓	✓			

SLS-class, 197-CAN with *QUICK SERVICE

DRIVE	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ME 9.7 AMG	✓	✓			
EGSHDKG (Transmission)	✓	✓		✓	
UFPCAMG(Fuel pump)	✓	✓			
DSI (DIRECT SELECT interface)	✓	✓			

CHASSIS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ESP (Electronic Stability Program)	✓	✓		✓	
EPB (Electronic parking brake)	✓	✓			
TPM	✓	✓			
AIRMATIC	✓	✓			

BODY	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
CGW (Central Gateway)	✓	✓			
EIS (Electronic Ignition Switch)	✓	✓			
AB (SRS / Airbag)	✓	✓			
KG	✓	✓			
SAM-Drive	✓	✓	✓		
SAM-Rear	✓	✓			
WSS (Weight Sensing System)	✓	✓		✓	
AMGDRVU (AMG DRIVE UNIT)		✓			

INFO. and COMMUNICATION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
IC(Instrument Cluster)	✓	✓	✓	OIL RESET	
SCM (Steering Column Module)	✓	✓	✓		
DSI(DIRECT SELECT interface)	✓	✓			
PTS (Parktronic System)	✓	✓			
MOST – UCI(Media interface)	✓	✓			
MOST – COMMAND	✓	✓			
MOST – ZBE[COU](Audio/COMAND operating unit)	✓	✓			
MOST – ZAN(Audio/COMAND display)	✓	✓			
MOST – DAB(Digital Audio Broadcasting)		✓			
MOST – SDAR(Satellite digital audio radio)		✓			
MOST – SOUND (SOUND System)		✓			
MOST – TV (TV Tuner)		✓			
MOST – DTA(TELEAID)		✓			
MOST – DTA (TELEAID) - Emergency call		✓			
MOST – DTA (TELEAID) - MB Info / Breakdown assistance		✓			
MOST – DTA (TELEAID) - Stolen vehicle tracking		✓			
MOST – DTA (TELEAID) - Vehicle remote unlocking/locking		✓			
SEATS AND DOORS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
DCM FL	✓	✓	✓		
DCM FR	✓	✓	✓		
ESA – Driver	✓	✓	✓		
ESA – Passenger		✓			
AIR CONDITION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
C-AAC / AAC (Automatic Air Conditioning)		✓		✓	

CLS-class, 219-CAN

DRIVE	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ME 2.8 / 2.8 AMG	✓	✓	✓	✓	
ME 9.7	✓	✓	✓	✓	
EGS 722.6 (5-speed automatic ETC)	✓	✓	✓	✓	
EGS 722.6 (5-speed automatic SEQ)	✓	✓			
EGS 722.9	✓	✓		✓	
ESM (Electronic Selector Module)	✓	✓		✓	
DTR (Distronic)		✓			
CDI 4	✓	✓		✓	

CHASSIS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ESP (Electronic Stability Program)	✓	✓			
AIRMatic	✓	✓			
SBC	✓	✓		✓	
TPC	✓	✓			

BODY	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
CGW (Central Gateway)		✓			
EIS (Electronic Ignition Switch) / KG(keyless)	✓	✓			
AB (SRS / Airbag)	✓	✓			
SAM-Driver		✓			
SAM-Passenger		✓			
SAM-Rear		✓			
RevETR-FL	✓	✓			
RevETR-FR	✓	✓			
OCP		✓		✓	
LCP (Lower Control)		✓			
UCP (Upper Control)		✓			
HRA		✓			
WSS (Weight Sensing System)	✓	✓		✓	
System Diagnosis		✓			
BCM	✓	✓			

*SHORT TEST: Searching for all systems, clear fault code if existed in one button.

*QUICK SERVICE: Perform "Service Reset" within seconds.

CLS-class, 219-CAN (continued)

INFO. and COMMUNICATION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ICM(Instrument Cluster)	✓	✓			
ASSYST (Active Service System)	✓	✓			
ASSYST PLUS (PLUS Active Service System)		✓		✓	
PTS (Parktronic System)		✓			
SCM (Steering Column Module)		✓			
MOST – AGW	✓	✓		✓	
MOST – COMMAND / AUDIO		✓			
MOST – CDC (CD Changer)		✓			
MOST – HFS (Handsfree System and Microphone)		✓			
MOST – CTEL (Cellular Telephone)		✓			
MOST – VCS (Voice Control)		✓			
MOST – NAVI (Navigation)		✓			
MOST – SOUND (Bose SOUND System)		✓			
MOST – TV (TV Tuner)		✓			
MOST – SDAR (Satellite Radio)		✓			

SEATS AND DOORS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
DCM FL	✓	✓	✓		
DCM FR	✓	✓	✓		
DCM RL	✓	✓	✓		
DCM RR	✓	✓	✓		
ESA – Driver	✓	✓			
ESA – Passenger	✓	✓			
DS-FL (Front Left Dynamic Seat)	✓	✓			
DS-FR (Front Right Dynamic Seat)	✓	✓			
DSP (Pneumatic pump for Dynamic Seat)	✓	✓			
TLC (Trunk Lid Control)	✓	✓			
HS (Seat Heater)	✓	✓			

AIR CONDITION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
C-AAC / AAC (Automatic Air Conditioning)	✓	✓	✓	✓	
HSW (Heated Steering Wheel)	✓	✓			

CLS-class, 218 with *QUICK SERVICE

DRIVE	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ME 9.7	✓	✓	✓	✓	
ME 9.7AMG	✓	✓			
MED9.7		✓			
MED40	✓	✓			
MED 17.7	✓	✓			
CDI6 OLS	✓	✓			
CDI6 EU5	✓	✓			
CDID 3	✓	✓			
EGS 722.9	✓	✓			
FSCU (Fuel pump)	✓	✓			
SGR (Radar sensors control unit)	✓	✓			
DTR (Distronic)	✓	✓			
DSI (DIRECT SELECT interface)	✓	✓			
ISM (Intelligent servo module)	✓	✓		✓	

CHASSIS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ESP (Electronic Stability Program)	✓	✓		✓	
AIRmatic	✓	✓			
EPS(Electrical power steering)	✓				
TPC(Tire Pressure Control)	✓	✓			

BODY	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
CGW (Central Gateway)		✓			
AB (SRS / Airbag)	✓	✓			
EIS (Electronic Ignition Switch)	✓	✓			
KG (Keyless Go)	✓	✓			
XALWA L (Xenon headlamp ,Left)	✓	✓			
XALWA R (Xenon headlamp ,Right)	✓	✓			
SAM-FRONT	✓	✓	✓		
SAM-REAR	✓	✓			
WSS (Weight sensing system)	✓	✓		✓	
OCP (Overhead control panel)	✓	✓		✓	
RevETR-LF	✓	✓			
RevETR-RF	✓	✓			
AHE (Trailer recognition)	✓	✓			

CLS-class, 218 with (continue)

INFO. and COMMUNICATION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ICM(Instrument Cluster)	✓	✓	✓	✓ (Service reset)	
SCM (Steering Column Module)	✓	✓	✓		
PTS (Parktronic System)	✓	✓			
NSA (Night View Assist)	✓	✓			
IRS-HRA (Outer right rear intelligent radar sensor system)		✓			
IRS-HLA (Outer left rear intelligent radar sensor system)		✓			

SEATS AND DOORS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
DCM FL	✓	✓	✓		
DCM FR	✓	✓	✓		
DCM RL	✓	✓	✓		
DCM RR	✓	✓	✓		
ESA – Driver	✓	✓			
ESA – Passenger	✓	✓			
PPAMKS (Pneumatic pump for active multicontour seat)	✓	✓			
AMKS LF (Active multicontour seat (Driver))	✓	✓			
AMKS RF (Active multicontour seat (Passenger))	✓	✓			
HKS (Tailgate control)	✓	✓			

AIR CONDITION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
AAC (Automatic Air Conditioning)	✓	✓	✓	✓	
HSW (Heated steering wheel)		✓			

CL-class, 215 (nonCAN) with *QUICK SERVICE & *SHORT TEST

DRIVE	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ME 1.0	✓	✓	✓	✓	✓
ME 2.0 / 2.0 V8	✓	✓	✓	✓	✓
ME 2.8 / 2.8 AMG	✓	✓	✓	✓	
ME 2.7	✓	✓			
EGS 722.6 (5-speed automatic ETC)	✓	✓	✓	✓	
EGS 722.6 (5-speed automatic SEQ)	✓	✓			
ESM (Electronic Selector Module)	✓	✓		✓	
DTR (Distronic)		✓			
CDI 2	✓	✓	✓		

CHASSIS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ESP (Electronic Stability Program)	✓	✓			
ABC (Active Body Control)	✓	✓	✓	✓	
TPC (Tire Pressure)	✓	✓			

BODY	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
EIS (Electronic Ignition Switch)	✓	✓			
AB (SRS / Airbag)	✓	✓			
HRA	✓	✓			
SAM-FRONT LEFT	✓	✓		✓	
SAM-FRONT RIGHT	✓	✓			
SAM-REAR	✓	✓		✓	
PSE (Pneumatic system)		✓			
OCP	✓	✓			
UCP (Upper Control)	✓	✓			
KG	✓	✓			
AHE (Trailer recognition)		✓			
SVMCM		✓			

CL-class, 215 (nonCAN) with *QUICK SERVICE & *SHORT TEST (continued)

SEATS AND DOORS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
DCM FL	✓	✓			
DCM FR	✓	✓			
DCM RL	✓	✓			
DCM RR	✓	✓			
ESA – Driver	✓	✓			
ESA – Passenger	✓	✓			
ESA – R	✓	✓			
OSB-FL (Multicontour backrest front left)	✓	✓			
OSB-FR (Multicontour backrest front Right)	✓	✓			
OSB-R (Multicontour backrest rear)	✓	✓			

INFO. and COMMUNICATION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ICM(Instrument Cluster)	✓	✓		Service Reset / Oil Quality	
SCM (Steering Column Module)	✓	✓			
PTS (Parktronic System)	✓	✓			
D2B	✓	✓		✓	
D2B – CDC (CD Changer)		✓			
D2B – CTEL1 (Cellular Telephone)		✓			
D2B – CTEL2 (Cellular Telephone)		✓			
D2B – VCS (Voice Control)		✓			
D2B – SOUND (Bose SOUND System)		✓			
D2B – TV (TV Tuner)		✓			
D2B – TELE AID		✓			
D2B – DN		✓			

AIR CONDITION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
AAC (Automatic Air Conditioning)	✓	✓			
KLA (Climate Control)	✓	✓			
REAR AC	✓	✓			
STH (Stationary Heater)	✓	✓			
HSW (Heated Steering Wheel)	✓	✓			
TSTH (Radio Remote Control STH)		✓			

CL-class, 215-CAN with *QUICK SERVICE & *SHORT TEST

DRIVE	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ME 2.8 / 2.8 AMG	✓	✓	✓	✓	
ME 2.7	✓	✓			
ME 9.7	✓	✓	✓	✓	
EGS 722.6 (5-speed automatic ETC)	✓	✓	✓	✓	
EGS 722.6 (5-speed automatic SEQ)	✓	✓			
EGS 722.9	✓	✓		✓	
ESM (Electronic Selector Module)	✓	✓			
DTR (Distronic)		✓			
CDI 2	✓	✓	✓		

CHASSIS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ESP (Electronic Stability Program)	✓	✓			
ABC (Active Body Control)	✓	✓	✓	✓	
TPC (Tire Pressure)	✓	✓			

BODY	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
CGW (Central Gateway)		✓			
EIS (Electronic Ignition Switch)	✓	✓			
AB (SRS / Airbag)	✓	✓			
RevETR-LF (Left front reversible emergency tensioning retractor)	✓	✓			
RevETR-RF (Right front reversible emergency tensioning retractor)	✓	✓			
HRA	✓	✓			
HLCM-L (Left headlamp)	✓	✓			
HLCM-R (Right headlamp)	✓	✓			
KG (keyless Go)	✓	✓			
SAM-FRONT LEFT	✓	✓			
SAM-FRONT RIGHT	✓	✓			
SAM-REAR	✓	✓			
PSE (Pneumatic system)		✓			
OCP	✓	✓			
UCP (Upper Control)	✓	✓			
System Diagnosis		✓			
AHE (Trailer recognition)		✓			
SVMCM		✓			

CL-class, 215-CAN with *QUICK SERVICE & *SHORT TEST (continued)

SEATS AND DOORS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
DCM FL	✓	✓			
DCM FR	✓	✓			
DCM RL	✓	✓			
DCM RR	✓	✓			
ESA – Driver	✓	✓			
ESA – Passenger	✓	✓			
ESA – R	✓	✓			
DS-FL (Front Left Dynamic Seat)	✓	✓			
DS-FR (Front Right Dynamic Seat)	✓	✓			
DSP (Pneumatic pump for Dynamic Seat)	✓	✓			
OSB-FL (Multicontour backrest front left)	✓	✓			
OSB-FR (Multicontour backrest front Right)	✓	✓			
OSB-R (Multicontour backrest rear)	✓	✓			

INFO. and COMMUNICATION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ICM(Instrument Cluster)	✓	✓		Service Reset / Oil Quality	
SCM (Steering Column Module)	✓	✓			
PTS (Parktronic System)	✓	✓			
MOST – AGW	✓	✓		✓	
MOST – COMMAND / AUDIO		✓			
MOST – CDC (CD Changer)		✓			
MOST – HFS (Handsfree System and Microphone)		✓			
MOST – CTEL (Cellular Telephone)		✓			
MOST – VCS (Voice Control)		✓			
MOST – NAVI (Navigation)		✓			
MOST – SOUND (Bose SOUND System)		✓			
MOST – TV (TV Tuner)		✓			
MOST – SDAR (Satellite Radio)		✓			
D2B	✓	✓		✓	
D2B – CDC (CD Changer)		✓			
D2B – CTEL1 (Cellular Telephone)		✓			
D2B – CTEL2 (Cellular Telephone)		✓			
D2B – VCS (Voice Control)		✓			
D2B – SOUND (Bose SOUND System)		✓			
D2B – TV (TV Tuner)		✓			
D2B – DN		✓			

CL-class, 215-CAN with *QUICK SERVICE & *SHORT TEST (continued)

AIR CONDITION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
AAC (Automatic Air Conditioning)	✓	✓			
REAR AC	✓	✓			
STH (Stationary Heater)	✓	✓			
HSW (Heated Steering Wheel)	✓	✓			
TSTH (Radio Remote Control STH)		✓			

CL-class, 216 with *QUICK SERVICE & *SHORT TEST

DRIVE	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ME 9.7	✓	✓	✓	✓	
EGS 722.6 (5-speed automatic SEQ)	✓	✓			
EGS 722.9	✓	✓		✓	
ISM (Intelligent servo module)	✓	✓	✓		
DTR (Distronic)		✓			
SGR (Radar sensors control unit)	✓	✓			

CHASSIS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ABR (Adaptive Brake)	✓	✓		✓	
ABC		✓		✓	
EPB (Electronic parking brake)	✓	✓			
TPC (Tire Pressure)	✓	✓			

BODY	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
CGW (Central Gateway)		✓			
EIS (Electronic Ignition Switch)	✓	✓			
AB (SRS / Airbag)	✓	✓			
WSS (Weight sensing system)	✓	✓		✓	
RevETR-LF (Left front reversible emergency tensioning retractor)	✓	✓			
RevETR-RF (Right front reversible emergency tensioning retractor)	✓	✓			
XALWA-L (Left headlamp)	✓	✓			
XALWA-R (Right headlamp)	✓	✓			
KG (keyless Go)	✓	✓			
SAM-Driver	✓	✓			
SAM-REAR	✓	✓			
OCP	✓	✓			
UCP (Upper Control)	✓	✓			
COU – ZBE (Central operating unit)	✓	✓			
HBF (Rear control field / panel)		✓			
System Diagnosis		✓			
BNS (Vehicle power supply control module)	✓	✓			
AHE (Trailer recognition)		✓			
SVMCM		✓			

CL-class, 216 with *QUICK SERVICE & *SHORT TEST(continued)

SEATS AND DOORS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
DCM FL	✓	✓	✓		
DCM FR	✓	✓	✓		
ESA – Driver	✓	✓			
ESA – Passenger	✓	✓			
DS-FL (Front Left Dynamic Seat)		✓			
DS-FR (Front Right Dynamic Seat)		✓			
DSP (Pneumatic pump for Dynamic Seat)		✓			
MKL-HL (Rear left Multicontour backrest)		✓			
MKL-HR (Rear right Multicontour backrest)		✓			
TLC (Truck lid control)	✓	✓			

INFO. and COMMUNICATION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
IC (Instrument Cluster)	✓	✓			
ASSYST (Active Service System)	✓	✓			
ASSYST PLUS (PLUS Active Service System)	✓	✓		✓(Service reset)	
NSA (Night View Assist)	✓	✓			
SCM (Steering Column Module)	✓	✓			
PTS (Parktronic System)	✓	✓			
RFK (Backup camera)	✓	✓			
COMAND		✓			
ZAN (Central Display)		✓			
TELE-AID		✓			

AIR CONDITION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
AAC (Automatic Air Conditioning)	✓	✓	✓	✓	
KBE-H (Rear A/C operating unit)	✓	✓			
STH (Stationary Heater)		✓			

R-class, 251 with *QUICK SERVICE & *SHORT TEST

DRIVE	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ME 9.7	✓	✓	✓	✓	
EGS 722.9	✓	✓		✓	
ISM (Intelligent servo module)	✓	✓	✓		
DTR (Distronic)		✓			
CDI 5	✓	✓			

CHASSIS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ENR (Electronic level control)	✓	✓		✓	
AIRmatic (Suspension)	✓	✓		✓	
ESP	✓	✓			
TPC (Tire Pressure)	✓	✓			

BODY	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
CGW (Central Gateway)		✓			
EIS (Electronic Ignition Switch) / KG (Keyless Go)	✓	✓			
AB (SRS / Airbag)	✓	✓			
WSS (Weight sensing system)	✓	✓		✓	
RevETR-LF (Left front reversible emergency tensioning retractor)	✓	✓			
RevETR-RF (Right front reversible emergency tensioning retractor)	✓	✓			
HRA (Headlamp)		✓			
SAM-Front	✓	✓		✓	
SAM-REAR	✓	✓		✓	
OCP	✓	✓		✓	
UCP (Upper Control)	✓	✓			
HBF (Rear control field / panel)	✓	✓			
System Diagnosis		✓			

R-class, 251 with *QUICK SERVICE & *SHORT TEST (continued)

SEATS AND DOORS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
DCM FL	✓	✓	✓		
DCM FR	✓	✓	✓		
ESA – Driver	✓	✓			
ESA – Passenger	✓	✓			
DS-FL (Front Left Dynamic Seat)	✓	✓			
DS-FR (Front Right Dynamic Seat)	✓	✓			
DSP (Pneumatic pump for Dynamic Seat)	✓	✓			
HS (Seat heater)	✓	✓			

INFO. and COMMUNICATION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ICM (Instrument Cluster)	✓	✓			
ASSYST (Active Service System)	✓	✓			
ASSYST PLUS (PLUS Active Service System)		✓		✓	
SCM (Steering Column Module)	✓	✓			
PTS (Parktronic System)		✓			
CM (Compass Module)	✓	✓			

AIR CONDITION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
AAC (Automatic Air Conditioning)	✓	✓	✓	✓	
STH (Stationary Heater)	✓	✓			
HSW (Heated steering wheel)	✓	✓			

M-class, 163 with SHORT TEST

DRIVE	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ME 2.0 / 2.1	✓	✓	✓	✓	✓
ME 2.8 / 2.8 AMG	✓	✓	✓	✓	
EGS 722.6 (5-speed automatic ETC)	✓	✓	✓	✓	
EGS 722.6 (5-speed automatic SEQ)	✓	✓			
ESM	✓	✓		✓	
TC / VG	✓	✓			
CDI 2	✓	✓	✓		

CHASSIS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ABS	✓	✓			
ASR	✓	✓			
ETS	✓	✓			
ESP (Electronic Stability Program)	✓	✓			
BAS (Brake Assist System)	✓	✓			
VP (Vacuum Pump Brake Booster)	✓	✓			

BODY	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
AB (SRS / Airbag)	✓	✓			
AAM (All Activity Module)	✓	✓		✓	
EAM (Extended Activity Module)	✓	✓		✓	
DAS (Drive Auth. System)	✓	✓			
LCP (Lower Control)	✓	✓			
HRA	✓	✓			
SEM (Security Module)		✓			

M-class, 163 with SHORT TEST (continued)

INFO. and COMMUNICATION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ICM / KI (Instrument Cluster)	✓	✓		Service Reset / Oil Quality	
PTS (Parktronic System)	✓	✓			
D2B (AUDIO System)	✓	✓		✓	
CDC (CD Changer)		✓			
CTEL (Cellular Telephone)		✓			
VCS		✓			
SOUND		✓			
TELE-AID		✓			

AIR CONDITION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
TAC (Tempmatic Air conditioning)	✓	✓	✓ (partial version)	✓ (partial version)	
STH (Stationary Heater)	✓	✓			

M-class, 164-CAN with *QUICK SERVICE & *SHORT TEST

DRIVE	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ME 2.8 / 2.8 AMG	✓	✓	✓	✓	
ME 9.7	✓	✓	✓	✓	
EGS 722.9	✓	✓		✓	
CDI 3	✓	✓			
CDI 4	✓	✓		✓	
TC / VG		✓			
ISM	✓	✓	✓		
HAQ		✓			

CHASSIS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ESP (Electronic Stability Program)	✓	✓			
AIRmatic (Suspension)	✓	✓		✓	
TPC (Tire Pressure)	✓	✓			

M-class, 164-CAN with *QUICK SERVICE & *SHORT TEST (continued)

BODY	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
CGW (Central Gateway)		✓			
EIS (Electronic Ignition Switch) / KG (Keyless Go)	✓	✓		✓	
AB (SRS / Airbag)	✓	✓			
RevETR-LF (Left front reversible emergency tensioning retractor)	✓	✓			
RevETR-RF (Right front reversible emergency tensioning retractor)	✓	✓			
HRA		✓			
SAM-FRONT	✓	✓			
SAM-REAR	✓	✓			
OCP	✓	✓		✓	
UCP (Upper Control)	✓	✓			
HBF (Rear Control Field)	✓	✓			
System Diagnosis		✓			
WSS (Weight Sensing System)	✓	✓		✓	
AHE (Trailer recognition)		✓			
SVMCM		✓			

SEATS AND DOORS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
DCM FL	✓	✓	✓		
DCM FR	✓	✓	✓		
ESA – Driver	✓	✓			
ESA – Passenger	✓	✓			
DS-FL (Front Left Dynamic Seat)	✓	✓			
DS-FR (Front Right Dynamic Seat)	✓	✓			
DSP (Pneumatic pump for Dynamic Seat)	✓	✓			
HS (Seat Heater)	✓	✓			

M-class, 164-CAN with *QUICK SERVICE & *SHORT TEST (continued)

INFO. and COMMUNICATION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ICM (Instrument Cluster)	✓	✓			
ASSYST (Active Service System)	✓	✓			
ASSYST PLUS (PLUS Active Service System)		✓		✓	
SCM (Steering Column Module)	✓	✓			
PTS (Parktronic System)		✓			
CM (Compass Module)	✓	✓			
MOST – AGW	✓	✓		✓	
MOST – COMMAND / AUDIO		✓			
MOST – CDC (CD Changer)		✓			
MOST – HFS (Handsfree System and Microphone)		✓			
MOST – CTEL (Cellular Telephone)		✓			
MOST – VCS (Voice Control)		✓			
MOST – NAVI (Navigation)		✓			
MOST – SOUND (Bose SOUND System)		✓			
MOST – TV (TV Tuner)		✓			
MOST – SDAR (Satellite Radio)		✓			

AIR CONDITION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
AAC (Automatic Air Conditioning)	✓	✓	✓	✓	
STH (Stationary Heater)	✓	✓			
HSW (Heated Steering Wheel)	✓	✓			

M-class, 166 with *QUICK SERVICE

DRIVE	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ME 9.7	✓	✓	✓	✓	
MED 17.7	✓	✓			
EGS 722.9	✓	✓		✓	
FSCU(Fuel pump)	✓	✓			
ISM (Intelligent servo module)	✓	✓			
SGR(Radar sensors control unit)	✓	✓			
DTR (Distronic)	✓	✓			
TC -Transfer case		✓			
CDI 6	✓	✓			
CDID 3	✓	✓			

CHASSIS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ESP (Electronic Stability Program)	✓	✓		✓	
AIRmatic (Suspension)	✓	✓		✓	
TPC (Tire Pressure)	✓	✓			
EPB (Electronic parking brake)	✓	✓	✓		

BODY	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
CGW (Central Gateway)	✓	✓			
EIS (Electronic Ignition Switch)	✓	✓			
AB (SRS / Airbag)	✓	✓			
KG	✓	✓			
SAM-Drive	✓	✓			
SAM-Rear	✓	✓			
RevETR-LF	✓	✓			
RevETR-RF	✓	✓			
SVMCM	✓	✓			
SD(Control module sliding roof)	✓	✓			

INFO. and COMMUNICATION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
IC(Instrument Cluster)	✓	✓		✓	
SCM (Steering Column Module)	✓	✓			
PTS (Parktronic System)	✓	✓			
MFK(Multifunction camera)	✓	✓			
RFK(Backup camera)	✓	✓			
NSA(Night View Assist)	✓	✓			
MOST – UCI(Media interface)	✓	✓			
MOST – COMMAND	✓	✓			
MOST – ZBE[COU](Audio/COMAND operating unit)	✓	✓			
MOST – ZAN(Audio/COMAND display)	✓	✓			
MOST – DAB(Digital Audio Broadcasting)		✓			
MOST – SDAR(Satellite digital audio radio)		✓			
MOST – SOUND (SOUND System)		✓			
MOST – TV (TV Tuner)		✓			
MOST – DTA(TELEAID)		✓			
MOST – DTA (TELEAID) - Emergency call		✓			
MOST – DTA (TELEAID) - MB Info / Breakdown assistance		✓			
MOST – DTA (TELEAID) - Stolen vehicle tracking		✓			
MOST – DTA (TELEAID) - Vehicle remote unlocking/locking		✓			
SEATS AND DOORS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
DCM FL	✓	✓			
DCM FR	✓	✓			
DCM RL	✓	✓			
DCM RR	✓	✓			
ESA – Driver	✓	✓			
ESA – Passenger	✓	✓			
HKS (Tailgate control)	✓	✓			
AIR CONDITION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
C-AAC / AAC (Automatic Air Conditioning)	✓	✓		✓	
STH (Stationary heater with remote control)		✓			

G-class, 463

DRIVE	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ME 2.0 / 2.1	✓	✓	✓	✓	✓
ME 2.8 / 2.8 AMG	✓	✓	✓	✓	
ME 9.7	✓	✓	✓	✓	
HFM	✓	✓	✓		
EGS 722.6 (5-speed automatic ETC)	✓	✓	✓	✓	
ESM	✓	✓		✓	
VGS		✓			
CDI 2	✓	✓	✓		
CDI V	✓	✓			
CDI 4(Common Rail Diesel Injection)	✓	✓		✓	
CDI 6(Common Rail Diesel Injection)	✓	✓			

CHASSIS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ABS	✓	✓			
ASR	✓	✓			
ETS	✓	✓			
ESP (Electronic Stability Program)	✓	✓			

BODY	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
AB (SRS / Airbag)	✓	✓			
ATA	✓	✓			
RFL		✓			
EIS	✓	✓		✓	
OCP		✓		✓	
UCP		✓			
SAM-FRONT		✓		✓	
SAM-REAR		✓		✓	
AHE		✓			
VR	✓	✓			
SVMCM		✓			

INFO. and COMMUNICATION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ICM / KI (Instrument Cluster)	✓	✓		Service Reset / Oil Quality	
D2B (AUDIO System)	✓	✓		✓	
CDC (CD Changer)		✓			
CTEL (Cellular Telephone)		✓			

VCS		✓			
SCM		✓			
APS		✓			
TV		✓			
TELE-AID		✓			

SEATS AND DOORS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
DCM FL	✓	✓			
DCM FR	✓	✓			
DCM RL	✓	✓	✓		
DCM RR	✓	✓	✓		
ESA – Driver		✓			
ESA – Passenger		✓			

AIR CONDITION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
AAC / TAC (Automatic Air conditioning)	✓	✓			
STH (Stationary Heater)	✓	✓			

GL-class, X164-CAN with *QUICK SERVICE & *SHORT TEST

DRIVE	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ME 2.8 / 2.8 AMG	✓	✓	✓	✓	
ME 9.7	✓	✓	✓	✓	
EGS 722.9	✓	✓	✓	✓	
CDI 3	✓	✓			
CDI 4	✓	✓		✓	
TC / VG		✓			
ISM	✓	✓	✓	✓	
HAQ		✓			
DTR		✓			
FSCU(Fuel pump)	✓	✓			

CHASSIS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ESP (Electronic Stability Program)	✓	✓		✓	
AIRmatic (Suspension)	✓	✓		✓	
TPC (Tire Pressure)	✓	✓			

GL-class, X164-CAN with *QUICK SERVICE & *SHORT TEST (continued)

BODY	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
CGW (Central Gateway)		✓			
EIS (Electronic Ignition Switch)	✓	✓		✓	
AB (SRS / Airbag)	✓	✓			
RevETR-LF (Left front reversible emergency tensioning retractor)	✓	✓			
RevETR-RF (Right front reversible emergency tensioning retractor)	✓	✓			
HRA		✓			
SAM-FRONT	✓	✓			
SAM-REAR	✓	✓			
OCP	✓	✓		✓	
UCP (Upper Control)	✓	✓			
HBF (Rear Control Field)	✓	✓			
System Diagnosis		✓			
WSS (Weight Sensing System)	✓	✓		✓	
AHE (Trailer recognition)		✓			
KG (Keyless Go)		✓			

SEATS AND DOORS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
DCM FL	✓	✓	✓		
DCM FR	✓	✓	✓		
ESA – Driver	✓	✓			
ESA – Passenger	✓	✓			
DS-FL (Front Left Dynamic Seat)	✓	✓			
DS-FR (Front Right Dynamic Seat)	✓	✓			
DSP (Pneumatic pump for Dynamic Seat)	✓	✓			
HS (Seat Heater)	✓	✓			
ERA (Electric fold-down backrest system)	✓	✓			
REDC (Rear-end door closing control module)	✓	✓			

GL-class, X164-CAN with *QUICK SERVICE & *SHORT TEST (continued)

INFO. and COMMUNICATION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ICM (Instrument Cluster)	✓	✓			
ASSYST (Active Service System)	✓	✓			
ASSYST PLUS (PLUS Active Service System)		✓		✓	
SCM (Steering Column Module)	✓	✓			
PTS (Parktronic System)		✓			
CM (Compass Module)	✓	✓			
MOST – AGW	✓	✓		✓	
MOST – COMMAND / AUDIO		✓			
MOST – CDC (CD Changer)		✓			
MOST – HFS (Handsfree System and Microphone)		✓			
MOST – CTEL (Cellular Telephone)		✓			
MOST – VCS (Voice Control)		✓			
MOST – NAVI (Navigation)		✓			
MOST – SOUND (Bose SOUND System)		✓			
MOST – TV (TV Tuner)		✓			
MOST – SDAR (Satellite Radio)		✓			
AIR CONDITION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
AAC (Automatic Air Conditioning)	✓	✓	✓	✓	
STH (Stationary Heater)	✓	✓			
HSW (Heated Steering Wheel)	✓	✓			

GL-class, X166 with *QUICK SERVICE

DRIVE	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
MED 17.7	✓	✓			
CDI6 OLS	✓	✓			
CDID 3	✓	✓			
EGS 722.9	✓	✓			
FSCU (Fuel pump)	✓	✓			
ISM (Intelligent servo module)	✓	✓		✓	
SGR (Radar sensors control unit)	✓	✓			
DTR (Distronic)	✓	✓			
SCR	✓	✓			

CHASSIS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ESP (Electronic Stability Program)	✓	✓		✓	
EPB (Electronic parking brake)	✓	✓			
AIRmatic	✓	✓			
EPS(Electrical power steering)	✓	✓			
TPC(Tire Pressure Control)	✓	✓			

BODY	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
CGW (Central Gateway)	✓	✓			
AB (SRS / Airbag)	✓	✓			
EIS (Electronic Ignition Switch)	✓	✓			
KG (Keyless Go)	✓	✓			
SAM	✓	✓			
Rear (Rear control unit)	✓	✓			
RevETR-LF	✓	✓			
RevETR-RF	✓	✓			
SVMCM	✓	✓			
SD (sliding roof)	✓	✓			

INFO. and COMMUNICATION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ICM(Instrument Cluster)	✓	✓	✓	✓ (Service reset)	
SCM (Steering Column Module)	✓	✓			
PTS (Parktronic System)	✓	✓			
MFK(Multifunction camera)	✓	✓			
RFK (Backup camera)	✓	✓			
NSA (Night View Assist)	✓	✓			

GL-class, 166 (continue)

SEATS AND DOORS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
DCM FL	✓	✓	✓		
DCM FR	✓	✓	✓		
DCM RL	✓	✓	✓		
DCM RR	✓	✓	✓		
ESA – Driver	✓	✓			
ESA – Passenger	✓	✓			
HKS (Tailgate control)	✓	✓			
AIR CONDITION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
AAC (Automatic Air Conditioning)	✓	✓		✓	

SPRINTER 901,902,903,904,905

DRIVE	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ME 2.0 / 2.1	✓	✓	✓	✓	✓
EGS 722.6 (5-speed automatic ETC)	✓	✓	✓	✓	
ESM (Electronic Selector Module)	✓	✓		✓	
CDI 1	✓	✓		✓	
CDI 1.7	✓	✓			
CDI 2	✓	✓	✓		
IFI	✓	✓			

CHASSIS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ABS	✓	✓			
ASR	✓	✓			
ETS	✓	✓			
ESP (Electronic Stability Program)	✓	✓			

BODY	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
AB (SRS / Airbag)	✓	✓			

INFO. and COMMUNICATION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ICM / KI (Instrument Cluster)	✓	✓		Service Reset / Oil Quality	
APS		✓			

AIR CONDITION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
AAC / TAC (Automatic Air conditioning)	✓	✓			
STH (Stationary Heater)	✓	✓			

SPRINTER 906-CAN

DRIVE	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
CDI 4	✓	✓		✓	
EGS 722.9	✓	✓	✓	✓	
ESM (Electronic Selector Module)	✓	✓			
VG	✓	✓			

CHASSIS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ESP (Electronic Stability Program)	✓	✓			
TPC	✓	✓		✓	

BODY	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
AAG(Trailer connection unit)		✓			
OCP(Overhead control panel)	✓	✓			
EIS(Electronic ignition switch)	✓	✓			
KE(Keyless Entry)		✓			
HRA(Headlamp range adjustment)	✓	✓			
SCM(Steering column module)	✓	✓			
UCP(Upper control panel)		✓			
SAM-F	✓	✓			
AB(Airbag)	✓	✓			

INFO. and COMMUNICATION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ICM / KI (Instrument Cluster)	✓	✓		Service Reset	
MTCO(Modular tachograph)		✓			
PTS(Parktronic system)		✓			
AGW(Audio gateway)		✓			

SEATS AND DOORS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
STL(Left electric sliding door)		✓			
STR(Right electric sliding door)		✓			
DCM(Door control module)	✓	✓			

AIR CONDITION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
AAC(Automatic air conditioning)	✓	✓			
PTC(Electric heater booster)	✓	✓			
STH(Auxiliary heater)	✓	✓			
ZHZ(Heater booster)	✓	✓			

VANEO

DRIVE	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ECM/MSM (Engine Control Monolith)	✓	✓			
CDI 1 (Common Rail Diesel Injection)	✓	✓			
ACS (Automatic Clutch System)		✓			
FTC (Front Transmission Control)		✓			
GRM (Gear Recognition Module)		✓			

CHASSIS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ESP (Electronic Stability Program)	✓	✓			
ESM	✓	✓		✓	

BODY	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
AB (SRS / Airbag)	✓	✓			
ATA (Anti-Thief Alarm)	✓	✓			
DAS (Drive Auth. System)	✓	✓			

INFO. and COMMUNICATION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ICM (Instrument Cluster)	✓	✓		Service Reset / Oil Quality	
PTS (Parktronic System)	✓	✓			
D2B (AUDIO System)	✓	✓		✓	
CDC (CD Changer)		✓			
CTEL1 (Cellular Telephone 1)		✓			

AIR CONDITION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
TAC / TAU (Tempmatic Air conditioning)	✓	✓			
STH (Stationary Heater)		✓			

VITO (638)

DRIVE	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ME 2.0 / 2.1	✓	✓	✓	✓	✓
CDI 1 (Common Rail Diesel Injection)	✓	✓			
CDI 2(Common Rail Diesel Injection)	✓	✓	✓		
IFI	✓	✓			

CHASSIS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ABS	✓	✓			

BODY	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
AB (SRS / Airbag)	✓	✓			

INFO. and COMMUNICATION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ICM (Instrument Cluster)	✓	✓		Service Reset / Oil Quality	
APS		✓			

AIR CONDITION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
TAC / TAU (Tempmatic Air conditioning)	✓	✓			
STH (Stationary Heater)		✓			

VITO / VIANO (639)

DRIVE	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ME 2.0 / 2.1	✓	✓	✓	✓	✓
CDI 3 (Common Rail Diesel Injection)	✓	✓			
ETC	✓	✓			
ESM	✓	✓			

CHASSIS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ESP	✓	✓			
ENR	✓	✓			
TPC	✓				

BODY	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
AB (SRS / Airbag)	✓	✓			
OCP		✓			
UCP	✓	✓			
SAM	✓	✓			
EIS		✓			
SDE-H		✓			
AAG		✓			

INFO. and COMMUNICATION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ICM (Instrument Cluster)		✓		Service Reset / Oil Quality	
APS		✓			
PTS	✓	✓			

SEATS AND DOORS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
DCM FL	✓	✓			
DCM FR	✓	✓			
ESA – Driver	✓	✓			
ESA – Passenger		✓			
ESD-L (left electric sliding door)		✓			
ESD-R (right electric sliding door)		✓			

AIR CONDITION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
TAC / TAU (Tempmatic Air conditioning)	✓	✓			
STH (Stationary Heater)		✓			
REAR-AC	✓	✓			
PTC(Electric heater booster)	✓	✓			

VITO / VIANO - CHINA (636)

DRIVE	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ME 9.7	✓	✓	✓	✓	
EGS 722.6 (5-speed automatic ETC)	✓	✓	✓	✓	
ESM (Electronic Selector Module)	✓	✓			

CHASSIS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ESP	✓	✓			
ENR	✓	✓			
TPC		✓			

BODY	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
AB (SRS / Airbag)		✓			
OCP		✓			
UCP	✓	✓			
SAM		✓			
EIS		✓			
AHE (Trailer recognition)		✓			

INFO. and COMMUNICATION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ICM (Instrument Cluster)		✓			
PTS	✓	✓			

SEATS AND DOORS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
DCM FL		✓			
DCM FR		✓			
ESA – Driver		✓			
ESA – Passenger		✓			
ESD-L (left electric sliding door)		✓			
ESD-R (right electric sliding door)		✓			

AIR CONDITION	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
AAC		✓			
STH (Stationary Heater)		✓			

VARIO

DRIVE	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ME 2.0 / 2.1	✓	✓	✓	✓	✓
CDI 1 (Common Rail Diesel Injection)	✓	✓			
CDI 2(Common Rail Diesel Injection)	✓	✓	✓		
IFI	✓	✓			

CHASSIS	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
ABS	✓	✓			

BODY	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
AB (SRS / Airbag)	✓	✓			

The information contained herein is the exclusive property of Autoland Scientech® and shall not be distributed, reproduced, or disclosed in whole or in part without prior written permission of Autoland Scientech®. Autoland Scientech® reserve the right to make any change without notice. The trademarks mentioned belong to the owners.